

---

WATER PURIFIER

---

USER GUIDE

---

CP-WN601HW

---

# CUCKOO

By MEX



Dear customers,  
Thank you very much for using  
CUCKOO Water Purifier.

Please retain this manual for future reference.  
This manual will be of great help should you have any questions or if the functions  
do not work properly.



### Merits of CUCKOO Water Purifier

- **4-Step Filtering System**  
The 4-step filtering system of CUCKOO Water Purifier dispenses clean and healthy water.
- **Stainless Steel Water Tank**  
We have increased the cleanliness in the water filtration process and the Tank by making the Water Tank with stainless steel.
- **Eco-Friendly Water Filtration System**  
We have applied a very economical and eco-friendly water filtration system without any wasted water during filtering process by using the Nano Positive Filter.
- **External Valve (Optional)**  
You can use the purified water also in your kitchen as the product is equipped with the External Valve.
- **Status Indicator Lights**  
Status Indicator Lights for hot water, cold water and sterilization make it convenient to check the operating status of the product at a glance.
- **Child Lock Button**  
We have applied a separate Child Lock Button to prevent children and other people from suffering burns.
- **Stylish design**  
Its slim and stylish design fits well in any place and provides excellent space utilization.
- **Separate Power Supply Switches for hot and cold water**  
The product is economical in enabling the hot water power and the cold water power to be turned ON and OFF separately.
- **Intake faucet sterilization system**  
It is possible to sterilize the intake cork with the Sterilizing Cup, which enables sanitary use of the water purifier.



## CONTENTS

<b>Before Use</b>	●	Warnings for Safe Use	4 ~ 7
		Cautions for Safe Use	8
		Name of Parts / Components Information	9
<b>How to Use</b>	●	Filtration Circuit / Water Filtration System	10
		Details to Check Before Installation	11
		How to Install the Product	12
		Details to Check Before Use	13
		Details to Check Before Use / How to Use	14
		How to Use / How to Use Faucet Sterilization	15
		How to Use Faucet Sterilization	16
		How to check filter change alarm function	17
		How to Clean the Cold Water Tank	18 ~ 20
		How to Clean Tray / Wash Faucet	21
		How to Replace the Filter	22 ~ 24
		Expected Filter Replacement Cycle / Recommendations / Filter Arrangement	25
<b>Before Asking for Support</b>	●	Please Check Before Asking for Support	26 ~ 27
<b>Service Guide</b>	●	Product Specification	28
		Warranty	28 ~29



## Warnings for Safe Use

- Please comply with the 'Warnings for Safe Use' as they are provided to ensure safe and proper use of the product and prevent accidents and dangerous situations.
- The 'Warnings for Safe Use' are made of 'Warning' and 'Caution', which mean the following respectively:

### **Warning**

Potentially dangerous situation that can cause serious injuries or death if not avoided.

### **Caution**

Potentially dangerous situation that can cause minor injuries if not avoided.



- This symbol is to remind you to be cautious about a potentially dangerous situation under special circumstances.

- Please read the details carefully and follow the instructions to avoid dangerous situations.



- This symbol is used to indicate actions that are prohibited. Potentially dangerous situation that can cause serious injuries or death if not avoided. Potentially dangerous situation that can cause minor injuries if not avoided.



- This symbol is used to indicate 'instructed' actions.


## About Power Supply

### **Warning**

Use only a Power Outlet exclusively for alternating current voltage of 220V~ at the rated current of 10A or higher with ground connection.


Do not put the Power Plugs of several products in one Power Outlet.

- If you use a Power Outlet for several products or use the Power Outlet also for any other device at the same time, it may cause heat, fire, and electric shock. Please check the condition of the Power Outlet on a frequent basis.
- When there are foreign substances or moisture on the Power Plug, wipe them out before use.
- Use an extension cord of 10A or higher.




Do not excessively bend, tie, or pull the Power Cord.

- It may cause electric shock or fire due to a short circuit. Check the condition of the Power Cord on a frequent basis.




If the Power Cord or the Power Plug is damaged or the Power Outlet is shaky, stop using them and contact our Customer Service Center.

- Carelessness during use may cause the Power Cord to be peeled off or chopped and cause fire and electric shock. Thus, frequently check the condition of the Power Cord, Power Plug, and Power Outlet.
- When the Power Cord or the Power Plug is damaged, have them replaced by the manufacturer, the seller, or a qualified technician (the service provider) to prevent danger.
- Have the product repaired by the designated Service Center. It may cause electric shock, short circuit, and fire.



Remove the foreign substances on the Power Plug with a dry cloth.

- They may cause electric shock, shock, and fire.
- Check the condition of the Power Plug on a frequent basis.



## Warnings for Safe Use



### About Power Supply




Warning



Prohibitions


**Pull the Power Plug by holding the Power Plug itself, not the Power Cord.**

- An impact to the Power Cord may cause electric shock and fire. Check the condition of the Power Plug and the Power Cord on a frequent basis.




**Use only one for the alternating current voltage of 220V~.**

- This may cause electric shock or fire.
- The product will not operate properly.
- Please check the state of the power cord and plug frequently.




**Pull the Plug out when there is water leak or when you are cleaning the product.**

- There is a risk of electric shock or malfunction. Check the condition of the Power Plug and the Power Cord on a frequent basis.




**Do not plug or unplug the power plug with wet hands.**

- If you hold the Power Plug with a wet hand, it may cause electric shock. Pulling the power cord by excessive force can damage the cord, causing a short circuit or electric shock.
- Check the condition of the Power Plug and the Power Cord on a frequent basis.




**Prevent the Power Cord from being under a heavy thing or getting in contact with a sharp edge, and avoid having it damaged by pets.**

- If the power cord is damaged, it may cause electric shock or fire. Please check the state of the power cord frequently.




**If the power supply area is wet, unplug the product and let it dry completely before Use.**

- This may cause electric shock or fire. Please check the state of the power cord and plug frequently.




**Turn the power OFF through the Power Supply Button. Also, pull the Power Plug out when you are repairing or checking the product or replacing a part.**

- There is a risk of malfunction or electric shock. Check the condition of the Power Plug and the Power Cord on a frequent basis.



**If you do not use the product for a long time, close the Tap Water Supplying Valve, drain all the water inside the Tank, and pull the Power Plug out.**

- If you do not do so, it may cause electric shock or fire. Check the condition of the Power Plug and the Power Cord on a frequent basis.
- Refer to the 'Matters To Check before Use' when you are reusing it.



ENG



## Warnings for Safe Use

### Installation Issues



Warning



Prohibitions

Please avoid the area where there is high moisture and dust.


- If you do not do so, it may cause electric shock or fire.



Do not install the product near the bathroom.


Do not install the product on a bumpy or inclined surface, liner, sitting cushion, or linoleum.

- It may cause product malfunction, unwanted noise or injury. Please check the condition of the product on a frequent basis
- This fixed type product should be fixed when you use.




Install the product avoiding direct sunlight and high temperature.

- It may cause colour changes or discolouration.
- Check the condition of the Power Cord on a frequent basis.




This product should not be used by people including children who lack physical or mental abilities, experience and knowledge to use the product properly without instruction.

- Do not let children play with the product.
- It may cause electric shock or injury.




Install the product where the length of the Tap Water Supplying Tube connected to the product will be 5m or shorter from the Tap Water Supplying Valve.

- If you do not do so, it may cause the performance of the product to be inefficient.




Do not install the product where gas may leak or somewhere near to an air conditioner or a heater.

- There is a risk of explosion or fire.




Use tap water as the supplying water, and install the Tap water supplying valve to the "Cold" water pipe.

- Do not use underground water or any other water than tap water.
- The replacement cycle of the filter will vary according to the region and the amount of water use.
- Connecting the water supply valve to the hot water pipe may cause damage to the filter or malfunction of the product.



Do not install the product at a place where the temperature goes down to 0°C or lower or outdoors.

- It may cause the Filter or the internal components to freeze, causing malfunction of the product.



When the surrounding temperature goes down to 0°C or lower in winter, sometimes the water inside the Filter and the Tubing Line may freeze, leading to damage. Thus, prevent the surrounding temperature of the place of installation from going down to 0°C or lower.

- When the surrounding temperature goes down to 0°C or lower and tap water freezes not to be supplied normally, turn OFF the hot water for safety.

## Warnings for Safe Use




### Warning

### Prohibitions


Do not put an electric heating appliance such as a microwave oven and an electric oven toaster or inflammables such as candlelight, gas can, and lighter on the product.

- There is a risk of fire, electric shock or accidents.




Do not put drugs, water bottle, small metal things, etc. on the product.

- If those things go into the product, it may cause a danger of fire or damage to the product.




When you move the product, do not pull the Power Cord or connecting tube or hold the Faucet part.

- It may cause a damage to the product. Check the condition of the Power Cord on a frequent basis.



Do not disassemble or remodel the product.

- It may cause fire or electric shock.
- Do not let anyone other than a service provider disassemble or collect the product.
- Contact Customer Service center for repair and AS service.



During use, prevent your hands or other body parts from contacting the Condenser part at the back of the product as it is hot.

- If you do not do so, it may cause burns or accidents.

Do not turn on the "Cold & Hot" buttons when the tank is empty.


- Failure to follow these instructions will result in damage to the unit, and CUCKOO will not be responsible for any related damages.
- First open the tap water valve to check if the water is cut off. Do not press the "Cold" & "Hot" buttons when the tank is empty. Fill the tank fully with water before pressing "Cold" & "Hot" buttons.
- If the "Hot" button is pressed when the tank is empty, the safety product will be turned on automatically to prevent the heater from running. This will cause lukewarm water to be extracted. Please contact Customer Service Center.

### Warning

### Instructions


If water leaks from the inside of the product or water is collected around the product, close the Tap Water Supplying Valve, turn OFF the Power Supply Button, pull out the Power Plug, and then contact our Customer Service Center.

- This may cause electric shock.



If a burning smell or smoke comes out from the product, pull out the Power Plug, close the Tap Water Supplying Valve, and contact our Customer Service Center.

- There is a risk of fire.



Be careful when using hot water.


- The hot water is very hot and it may cause burns. Thus, avoid touching the hot water with your hands and be cautious when children and the elderly and the infirm are using the product.



Let only the service provider from our Service Center do the installation and disassembly of the product.


They may cause fire or discoloration of the product.

- Secure the distance from the wall of 20cm.



When replacing the filter, lock the water supply valve (adapter). (The water supply valve is usually located under the sink or in the faucet.)

- It causes a leak.






## Cautions for Safe Use

### ⚠ Cautions    ! Prohibitions


Close the Tank Cover inside the product and the Top Cover of the product firmly before use.

- Foreign substances may go into the product.




Replace the Filter at the replacement cycle.

- It may reduce the purification function or cause bad odour.
- Refer to page 24 for the filter replacement cycle.



If you do not use the product for a long time, first completely drain the water inside the Tank, fill the Tank with water, and drain the water completely again before use.

- When you drain the water from inside the Cold Water Tank, about 3.8L of water will come out.
- When you drain the water from inside the Hot Water Tank, about 2.4L of water will come out. If you drain hot water before draining cold water. Drain the cold water first, and then drain the hot water.



Please use only CUCKOO Filter (genuine)

- If you use any filter other than the genuine CUCKOO filter, it may cause a decrease in water purifying performance, an abnormal taste of water, water leak, and a malfunction of the product.

If you have not used the External Faucet for a long time (one day or longer), it may be polluted. If you reuse the External Faucet, you can use the purified water after draining water for about one to two minutes.

Do not use the water of the Water Purifier to replace water in a fishbowl or aquarium.


- The room temperature water may not be suitable for the environment for fish. They may die depending on the circumstances.

- ※ Sterilized water is not potable water. Please be careful not to drink sterilized water.
- ※ Use sterilizing water for sterilizing fruits, vegetables, and furniture, and wash it with room temperature water.
- ※ There is still water left in the faucet valve after the sterilization water is used, so let water flow for about 3 seconds after using the sterilizing water.

### ⚠ Cautions    / Prohibitions


Do not clean the product with benzene and thinner.

- It may cause a damage to the product.




Do not move the product while it is working.

- Do not move or shake the product with the power supply is ON. It may cause the connecting tube to be released, leading to a malfunction of the product and water leakage.



Do not pull out the Tube from the back of the product while using the product.


- It may cause water leak and malfunction of the product.





## Name of Parts / Components Information

### Name of Parts



ENG

### Components Information



User Manual



Service Card



External Valve (Optional)




Sterilization Cup




## Filtration Circuit / Water Filtration System

### Filtration Circuit



### Water Filtration System



Steps	Filter Name	Filter Function
Step 1	Sediment Filter	Removes rust and floating matter.
Step 2	Pre-Carbon Block 2.0 Filter	Removes residual chlorine and organic substances.
Step 3	Natural 2.0 Filter	Contains minerals and removes odors and organic substances.
Step 4	Nano Positive 3.0C Filter	Removes germs, viruses(Norovirus), particles, heavy metals including iron, aluminum.

\* If Cuckoo Filter (genuine) is not used or used for a prolonged period, it may show reduced performance.






## Details to Check Before Installation



### Details to Check Before Installation

#### ⚠ Precautions for Place of Installation

- 1 Please avoid direct sunlight or electric heating appliances.**
  - ▶ It may cause fire and/or discoloration of the product.
- 2 Secure sufficient installation space.**
  - ▶ Considering convenience during a filter exchange, secure at least 20cm from walls, and install it in a place where the length of the water supply hose is less than 5m from the water supply valve.
- 3 Avoid installing the product in a place with much humidity, dust and/or direct splashes of water.**
  - ▶ It may cause a malfunction of the product.
- 4 Avoid any uneven surface, slope or unsolid place.**
  - ▶ It may cause fire and/or damage to the product.
- 5 Avoid a place where the temperature drops below 0°C.**
  - ▶ This product is for indoor use only. If installed in a place where the temperature drops below 0°C, the filter and the inside of the product may freeze, which may cause a malfunction of the product and/or water leak.



#### ⚠ Caution When Moving

- 1 Please be careful when you move the product.**
  - ▶ Please do not tilt it more than 45 degrees when moving it.
  - ▶ Please also make sure to plug it in at least about 30 minutes after filling the tank.



#### ⚠ Precautions on Connecting Pipes

- 1 Make sure to connect the water supply valve to the Cold Water Pipe.**
  - ▶ Connecting it to the hot water pipe may cause damage to the filter and a malfunction of the product.
  - ▶ For the hose connection method, refer to How to Install the Product (Page. 12).




\* When the Half type is installed on the sink, the vibration caused by operating the Compressor will be transmitted to it, leading to raise degrees of noise. Avoid installing near vibration.



## How to Install the Product

### How to Install the Product



**① Install the Tap Water Supply Valve on the side of the Cold Water Pipe.**

**\* Caution**

- Install the Tap Water Supply Valve in the Close state.
- Please make sure to connect the valve to the cold water pipe. Installing it on the Hot Water Pipe may cause damage to the filter and product.

**② Insert the Tap Water Supply Valve into the Water Inlet on the back of the product.**

**\* Caution**

- Connect it to the correct location of the Water Inlet. (Lock it with enough force so that a locking sound is heard. Otherwise, it may cause a water leak.)
- Connect the external tube when you install the external valve (Optional).

**③ Turn the Tap Water Supply Valve to Open.**

**④ Insert the power plug into an outlet.**

**⑤ After installation, check if water leaks from the hose connection part.**

- Tap Water Supply Valve (Tube)
- Water Inlet, Hot Water Drain, External Outlet
- External Valve (External Tube)
- Filter Connecting Tube

**\* Make sure to use tap water as the water source.  
Do not use other water sources, such as groundwater.**

## Details to Check Before Use



### Caution

**Do not turn on the Cold Water and Hot Water switches while the tank is empty (it may cause a malfunction of the product).**


- Turn on the Cold Water and Hot Water buttons after filling the tank with water up to the full water level.
- If the power is pressed with no water inside the tank, the safety mechanism will be activated for safety and, subsequently, the water heater cannot be heated, which produces lukewarm water. In this case, please contact our Customer Service Center.
- Frequently check if the water supply is disconnected and the Tap Water Supply Valve is closed, and do not turn on the Cold Water and Hot Water switches while the tank is empty.

ENG

### Details to Check Before Use


#### 1 Open the Tap Water Supply Valve.

- ▶ Turn the tap on first to check if the water is properly supplied. After that, open the Tap Water Supply Valve.




#### 2 Turn the Close lever of the filter door on the right side of the product to the direction of Close.

- ▶ Water is supplied to the water purifier.




#### 3 Connect the power.

- ▶ This product is exclusively for 220V~ and 50Hz. Please make sure to plug it into a proper outlet.
- ▶ Check for water disconnection before plug-in.
- ▶ Before connecting the power, check if the Cold Water and Hot Water buttons are turned off.




#### 4 Turn on the Hot Water or Cold Water switch.

- ▶ To use hot water, turn on the Hot Water switch and, to use cold water, turn on the Cold Water switch. Check that the "Hot" or "Cold" indicator is lit up.



Model	Hot	Cold
CP-WN601HW	Red	Blue



- #### 5 If the product has not been used for a long period of time or a new product has been installed, use it after completely emptying out the tank and repeating, at least once, the process of filling the tank with newly purified water and then discarding it.






## Details to Check Before Use / How to Use


### Details to Check Before Use

- 6 Empty out the Drip Tray on a regular basis.



- 7 Exchange and manage the filter on a regular basis.


- ▶ Please clean and replace the filters regularly so that you can always enjoy pure and clean water.
- ▶ For the filter replacement cycle, refer to Page 25.



### How to Dispense Hot Water

- 1 Press the Hot Water button to turn it on. The hot water heater requires a period of about 30 minutes to start up (red lamp lit).

- ▶ Before turning on the Hot Water button, first check if the water supply is disconnected and the Tap Water Supply Valve is closed.



- 2 Gently push the Hot Water Lever and press the Safety button.

Do not push the Hot Water Lever while the Safety button is pressed. It is to prevent burns from splashed hot water.



- 3 Lift the Hot Water Lever to 90° and press the Safety button for hot water to be discharged continuously.

After the continuous discharge, slowly return the lever to the original position (a quick return may splash the water and cause a burn).




## How to Use / How to Use Faucet Sterilization



### How to Use Cold Water and Room Water

- Turn on the Cold Water button. The cooler (compressor) requires a period of about 60 minutes to start up (blue lamp lit).

  - Before turning on the Cold Water button, first check if the water supply is disconnected and the Tap Water Supply Valve is closed.
- Turn the Select Lever to the direction of Cold Water or Room Water. Depending on the direction of the lever, either cold water or room water is discharged. (3 o'clock direction for cold water and 12 o'clock direction for room water)
- Gently push the Cold Water Lever.
- Lift the Cold Water Lever to 90° for cold water (room water) to be discharged.



The first cup may feel slightly lukewarm. This is because room water inside the water pipe is discharged together. Water will be discharged at a proper temperature starting with the second cup.

\* In a situation where either the Cold Water or Hot Water switch is turned off, be careful as room water may be too hot or cold.

### How to Enter Faucet Sterilization Standby Mode


- Adjust the Flow Path Conversion Valve so that it turns completely to the "Cold Water" direction.

  - If the Flow Path Conversion Valve points to the "Room Water" direction or is not completely turned to the "Cold Water" direction, water from inside the tank is discharged.
- Press the Sterilize button.

  - Only the Faucet Sterilization lamp blinks along with a button sound, and the alarm is sounded every minute.

If there is not enough water in the tank for sterilization, the alarm is sounded and it does not enter Standby Mode.
- Turn the Hot Water and Cold Water Lever to 90° to adjust the direction, and place the sterilization cup on the water tray; or place the sterilization cup on the water tray so that the hot and cold water levers can be pushed back.

  - Only the Faucet Sterilization lamp blinks along with a button sound, and the alarm is sounded every minute.
  - As shown in the image, place it by lifting it from below to above. Cold water is not discharged at this time.



\* Even after pressing the Faucet Sterilization button, a small amount of remaining water may come out when lifting the Cold Water Lever.

\* Check the blinking of the Faucet Sterilization lamp and then lift the lever.

\* Do not press the Hot Water Button during faucet sterilization. If you press it, hot water will be discharged continuously, which may cause a burn.

\* If you wish to disable it, refer to "How to Clear Faucet Sterilization Standby Mode" below.



## How to Use Faucet Sterilization

### *How to Clear Faucet Sterilization Standby Mode*

- 1 Remove the Sterilizing Cup from the Drip Tray, and lower the Hot Water/Cold Water Lever.
  - ▶ Only the Faucet Sterilization lamp blinks along with a button sound, and the alarm is sounded every minute. If the Faucet Sterilization button is pressed before lowering the lever, cold water is discharged.
- 2 Press the Faucet Sterilization button.
  - ▶ Along with a button sound, the lamp of Hot Water/Cold Water Switch is turned on or off depending on On/Off state of the switch.

### *How to Use Faucet Sterilization*

- 1 In the Faucet Sterilization Standby Mode (refer to Page 15), press the Faucet Sterilization button to start faucet sterilization.
  - ▶ Once faucet sterilization begins, "Hot Water → Faucet Sterilization → Cold Water" lamps are lit in order, and sterilization proceeds for 3 minutes.
    - \* Do not remove the Sterilizing Cup while faucet sterilization is in progress.
    - \* Once the Sterilizing Cup is removed, sterilization is cancelled along with the alarm and it enters the "Sterilizing Cup Error". (refer to "How to Clear Sterilizing Cup Errors" below)
- 2 Once faucet sterilization is complete, only the Faucet Sterilization lamp is lit along with the completion sound, and the alarm is sounded every minute.
  - \* If you wish to cancel sterilization while Faucet Sterilization is in progress, press the Faucet Sterilization button once again. However, if sterilized water has been produced, faucet sterilization will be cancelled completely after washing the sterilized water for 1 minute.
    - ▶ Faucet Sterilization feature can be performed only once each time and cannot be executed continuously.
    - ▶ To restart faucet sterilization, empty out the Sterilizing Cup, place it on the Drip Tray again, and press the Sterilization button.
      - \* If you proceed with faucet sterilization without emptying out the Sterilizing Cup, the sterilized water may overflow.
      - \* Sterilizing water is not for drinking. Be careful not to drink sterilized water.

### *How to Clear Sterilizing Cup Errors*

#### **Option 1) Place the Sterilizing Cup on the Drip Tray. (Recommended)**

- ▶ Only the Faucet Sterilization lamp blinks along with a button sound, and the alarm is sounded every minute (Faucet Sterilization Standby Mode).
- ▶ After sterilized water has been created, if the cup is removed and then placed on the Drip Tray again, the sterilized water is washed for 1 minute and then it enters the Faucet Sterilization Standby Mode. (The Faucet Sterilization lamp is lit, and the alarm is sounded every minute.)
  - \* If you wish to clear the Faucet Sterilization Standby Mode, refer to "How to Clear Faucet Sterilization Standby Mode" on Page 16.

#### **Option 2) Press the Sterilization button once.**


- ▶ Only the Faucet Sterilization lamp blinks along with a button sound, and the alarm is sounded every minute.
  - If you press the Sterilize button one more time, hot water/cold water will be discharged while sterilized water still remains in the faucet. So make sure to lower the Hot Water/Cold Water Lever to wash the faucet (refer to "How To Wash Faucet" on Page 21) and then discharge 2 cups each of hot water and cold water (300cc) before using the water purifier.

## How to check filter change alarm function



### How to check the filter that needs to be replaced

- 1 After connecting the product to power, the user is informed of when to replace the filter every four months. And using the number of blinking of the hot water, cold water, Faucet Sterilization LED guide filters that need to be replaced.



※ The filter alarm LED blink even when the product on/cold water switch is turned off.

※ When the product is powered off, the Filter usage time is reset.


Filters requiring replacement	indications
Sediment Filter	"Hot water LED" blinking
Sediment Filter Pre-Carbon Block 2.0 Filter	"Cold water LED" blinking
Sediment Filter Natural 2.0 Filter Nano Positive 3.0C Filter	"Hot water LED" "Cold water LED" blinking
Sediment Filter Pre-Carbon Block 2.0 Filter Natural 2.0 Filter Nano Positive 3.0C Filter	"Hot water" "Cold water" "Faucet Sterilization LED" blinking

### How to reset filter change alarm

This is the function is to turn off the filter change alarm and reset the replaced filter usage time.

- 1 How to reset filter usage  
(If the filter change alarm is displayed)

- ▶ After checking the filter alarm, press the Faucet Sterilization button for about 3 seconds.
- ▶ A button sound is generated when the reset Function is in operation. And the filter alarm LED is turned off.



- 2 How to reset filter usage  
(If the filter alarm is not displayed)

- ▶ ▶ Before the filter alarm is displayed, if the filter is replaced first in the next replacement cycle, press the Faucet Sterilization button for about 10 seconds to reset the filter usage time.

※ If reset the filter alarm before it works, the alarm for that filter does not appear and measures the filter usage time again.




## How to Clean the Cold Water Tank

### How to Use External Faucet (Optional)

- 1 Lift the lever on the External Valve, which is connected to the sink, to be able to use the External Faucet.

▶ In case the External Faucet is not used for a long period of time while the power is connected, Water from the External Valve may be warm due to the internal heat generated by the heater and compressor operations.


※ Scrubbing the External Valve with a brush or a dishwashing sponge may damage the plating and, also, cause minerals to become stuck on it.




If you have not used the External Faucet for more than a day, it can be polluted. When reusing the External Faucet, Room water can be used after draining water for about 1 to 2 minutes.

### How to Clean the Cold Water Tank


- 1 First, close the Tap Water Supply Valve.



- 2 Turn off the cold water and hot water switch.



- 3 For safety, make sure to unplug the power plug.



- 4 Completely drain the water from inside the Cold Water Tank through the Cold Water Faucet.

▶ It will be used again to clean the tank so keep the water in a clean bowl.  
 ▶ Adjust the Flow Path Conversion Valve so that it points to "Cold Water".  
 ▶ About 3.8L of water will be discharged so make sure to prepare a tank of a sufficient size.






## How to Clean the Cold Water Tank




### 5 Connect the Hot Water Drain Hose to the Hot Water Faucet and Hot Water Drain to completely empty out the Hot Water Tank.

- ▶ About 1.4L of water will be discharged for a half, respectively, so make sure to prepare a tank of a sufficient size.
- ▶ If hot water is discharged before cold water, about 2.4L of water will come out from a half, respectively. Discharge cold water before draining hot water (once hot water is completely discharged, make sure to close the cap of the Drain Valve).




### 6 Detach the cover at the top of the product.

- ▶ Please use a Phillips screwdriver.



### 7 Detach the cover of the Cold Water Tank and pull the Separator to detach it from the tank (before detaching the cover, separate the connected tube from the cable).


- ▶ When cleaning the inside of the tank, wear sanitary gloves to ensure cleanliness.



### 8 Use a soft, sanitary cloth to wipe the inside of the tank.

- ▶ Be careful not to leave any foreign substances inside the tank.

Mineral ingredients dissolved in water inside the tank may generate white particles. If you do not use the water purifier often, drain water through the Cold Water Faucet and Hot Water Faucet once every 2 to 3 days to prevent the formation of white particles. (It is recommended to use room water within a short amount of time.)



### 9 Pour the water, which was kept in Step 4, into the tank to wash it thoroughly.

- ▶ Completely drain the water used for washing through the Cold Water Faucet.
- ▶ Open the cap of the Hot Water Drain Valve to completely drain the water having flown in from the Hot Water Tank, and make sure to close the cap.






## How to Clean the Cold Water Tank

### 10 Reinstall the Separator onto the cold water tank.

- ▶ Press down on the Separator to prevent it from separating.

If the Separator is loose and not fixed, it will take a longer period of time for the compressor to operate, which may cause generation of noise. Make sure the Separator is firmly positioned.



### 11 Install the cover of the cold water tank.


- ▶ Completely shut the cover of the cold water tank.

In order to keep insects and foreign material away.




### 12 Close the top cover, fasten the screws, open the Tap Water Supply Valve, and then check if water flows out through the Cold Water Cork and Hot Water Cork.

- ▶ Fasten the screws with a Phillips driver.



### 13 Insert the power plug and press the cold water and hot water buttons.



- ▶ Check if water flows out through the Hot Water Faucet and then press the Hot Water button to turn on.  
※ Clean the tank on a regular basis to be able to drink clean and healthy water at all times.


## How to Clean Tray / Wash Faucet



### How to Clean Tray


#### 1 Detach the Tray.

- ▶ Hold and uplift the Tray to separate it from the product.




#### 2 Detach the Drip Tray Grille.

- ▶ Then detach the Drip Tray Grille from the Drip Tray by taking hold of and uplift the hole at the Grille.




#### 3 Clean the Tray.

- ▶ Dispose of the stagnant water, and completely wipe it out with a soft cloth.



#### 4 Assemble the Tray.


- ▶ After cleaning the Drip Tray, place the Tray back in reserve order.



### How To Wash Faucet

- ① Loosen the faucet cover by turning it in a clockwise direction.
- ② Loosen the faucet outlet by turning it in a clockwise direction.
- ③ Wash the faucet cover and faucet outlet in running water.

- ▶ Use sanitary gloves to enhance cleanliness.






## How to Replace the Filter


*How to Replace the Filter (Must not use non-CUCKOO Water Purifier Filters.)*

- 1 Close the Tap Water Supply Valve.




- 2 Remove any pressure (residual pressure) remaining inside the pipe.


▶ Place a cup below the Cold Water Faucet and drain about 3 to 4 cups of water (about 500cc).




- 3 Turn off the Cold Water and Hot Water button and unplug the power plug.



- 4 Turn the filter door lock lever on the right side of the product to the OPEN direction, and press the hook on the filter door to detach it.



- 5 Completely empty out the water purifier.




## How to Replace the Filter



### How to Replace the Filter (Must not use non-CUCKOO Water Purifier Filters.)

- 6 Lift and pull the filter to be replaced to detach it and replace it with a new filter. Then, slide it into the filter case.

▶ Be careful as residual water may come out from the filter. This is the water coming out of the filter, not water being leaked from the product.



- 7 After completing the filter replacement, close the filter cover and allow water to pass through the hose at the outlet depending on the following cases. (water can pass only if the Tap Water Valve is open).

**Case 1.** When replacing the Sediment Filter : Allow water to pass through for about 5 minutes.

**Case 2.** When replacing the Sediment and Pre-Carbon Block 2.0 Filters : Allow water to pass through for about 7 minutes.




**Case 3.** When replacing the Sediment, Natural 2.0 and Nano Positive Filters : Allow water to pass through for about 10 minutes.

**Case 4.** When replacing all filters : Allow water to pass through for about 10 minutes.

▶ Make sure that water is passed through for more than the recommended time to ensure the desired water quality.

▶ Once the process of passing water through the filter is complete, supply tap water and use a soft cloth, etc. to check if there is any water leakage.

<Half Type>







## How to Replace the Filter

### How to Replace the Filter (Must not use non-CUCKOO Water Purifier Filters.)



- 8 Close the cover for filter replacement on the right side of the product again and turn the door lock lever in the 'CLOSE' direction.



- 9 Open the Tap Water Supply Valve and repeat twice the process of completely filling the tank with water up to the full water level and then draining it.



- 10 Fill the tank with water completely and then connect the power plug to turn on the Cold Water and Hot Water switches.



## Expected Filter Replacement Cycle / Recommendations / Filter Arrangement



### Expected Filter Replacement Cycle

- ▶ Filter replacement cycle is determined based on 10L-per-day use in an ordinary household, and may be affected by the state of the water source.

Model	Filter Name	Expected Replacement Cycle
CP-WN601HW	Sediment Filter	4 months
	Pre-Carbon Block 2.0 Filter	8 months
	Natural 2.0 Filter	12 months
	Nano Positive 3.0C Filter	12 months

### Recommendations


#### ▶ Filtration Capacity

It refers to the minimum processing capacity with which pollutants can be removed effectively without having to clean, recycle and/or replace the filter inside a water purifier.

#### ▶ Filter exchange cycle

After a close review of filters, it is a carefully estimated period during which a filter is expected to display its proper performance. This is based on tap water as the inflowing water and about 10L-per-day use (drinking water for 4 people) so, if the volume of usage exceeds this level, the exchange cycle may be shortened.

### Filter Arrangement



## Please Check Before Asking for Support

- ▼ When the product is not used properly in compliance with the User Manual, the product may not operate properly even if it is no broken down. Please take the following measures accordingly if there is a problem with the product. Please contact customer service center if the problem could not solved with the measure below.

Problem	Checklist	Recommendation
The taste of water is unpleasant. There is bad smell.	<ul style="list-style-type: none"> <li>• Has it been a long time since you last used the Water Purifier?</li> <li>• Isn't it the time to replace the Filter?</li> <li>• Has it been a long time since you last used hot water?</li> </ul>	<ul style="list-style-type: none"> <li>• Drain the water from the Hot and Cold Water Tanks and clean the Cold Water Tank.</li> <li>• Replace the Filter (the genuine CUCKOO Filter).</li> <li>• Drain the water in the Hot Water Tank with the Hot Water Drain Tube, and frequently use hot water at the Hot Water Faucet usually.</li> </ul>
No water comes out.	<ul style="list-style-type: none"> <li>• Is tap water supplied smoothly?</li> <li>• Is the water pressure at your home low?</li> <li>• Are you getting cold water but not hot water?</li> <li>• Do you think there is a problem with the Hot/ Cold Water Lever?</li> </ul>	<ul style="list-style-type: none"> <li>• Open the Tap Water Supplying Valve.</li> <li>• Check if the Feed Tube is folded.</li> <li>• Check if water is cut off.</li> <li>• Mount the External Pump (for separate sale)/ Contact our Customer Service Center.</li> <li>• Push the Hot Water Lever and press the Child Lock Button.</li> <li>• Check if the Hot Water Indicator is red.</li> <li>• Check if power is turned on.</li> <li>※ If the product does not work even if you have taken the above measures, contact our Customer Service Center to receive our service.</li> <li>• Contact our Customer Service Center.</li> </ul>
The hot water temperature is too low.	<ul style="list-style-type: none"> <li>• Is the hot water indicator on?</li> <li>• Did you already extract a lot of hot water?</li> <li>• Does the water come out at room temperature?</li> </ul>	<ul style="list-style-type: none"> <li>• Press the "Hot" button to turn the Hot Water Indicator on.</li> <li>• If you dispensed all the hot water from the Hot Water Tank, you need to wait for about 30 minutes to re-heat the fresh supply of water.</li> <li>• Press the "Hot" button at the back of the product to turn it OFF, and contact our Customer Service Center.</li> </ul>



## Please Check Before Asking for Support

- ▼ When the product is not used properly in compliance with the User Manual, the product may not operate properly even if it is not broken down. Please take the following measures accordingly if there is a problem with the product. Please contact customer service center if the problem could not be solved with the measure below.

Problem	Checklist	Recommendation
The cold water temperature is too high.	<ul style="list-style-type: none"> <li>• Is the Cold Water Indicator turned on?</li> <li>• Have you dispensed a lot of cold water?</li> <li>• Have you dispensed a lot of cold water?</li> </ul>	<ul style="list-style-type: none"> <li>• Press the "Cold" button to turn on the Cold Water Indicator.</li> <li>• If you used all the cold water in the Cold Water Tank, you need to wait for approximately one hour to re-cool the water.</li> <li>• Check if the Radiator at the back of the product is blocked. Remove any objects blocking the Radiator. Move the product to a place with good ventilation and reinstall it. (Please contact our Customer Service Center when you move and reinstall the product.)</li> </ul>
The amount of room water has become smaller suddenly.	<ul style="list-style-type: none"> <li>• Haven't you closed the Tap Water Supplying Valve?</li> <li>• Hasn't the filter replacement cycle passed?</li> </ul>	<ul style="list-style-type: none"> <li>• Open the Tap Water Supplying Valve.</li> <li>• Replace the Filter (the genuine CUCKOO Filter).</li> </ul>
There is a loud noise coming from the product.	<ul style="list-style-type: none"> <li>• Is the floor where the product is installed flat?</li> <li>• Is the product contacting another thing?</li> <li>• Is sound made after extraction of water from the Faucet?</li> <li>• Is sound made after extraction of water from the Faucet?</li> </ul>	<ul style="list-style-type: none"> <li>• Install the product on a flat and firm surface.</li> <li>• Make sure the product is not in contact with other things.</li> <li>• As the Water Purifier has a direct-coupled water supply system, when the room water goes out through the Faucet, water comes in immediately. The noise is made when the water flows into the Cold Water Tank, and it is normal sound.</li> <li>• It is the sound of driving of the Pump working for supplying water to the Tank after water extraction, and it is a normal operation.</li> </ul>
There are floating matters in the dispensed water.	<ul style="list-style-type: none"> <li>• Hasn't the filter replacement cycle passed?</li> </ul>	<ul style="list-style-type: none"> <li>• Replace the Filter (the genuine CUCKOO Filter).</li> </ul>
Water is leaking from the Water Purifier.	<ul style="list-style-type: none"> <li>• Is the assembled (connecting) part defective?</li> <li>• Isn't your home or the external environment humid?</li> </ul>	<ul style="list-style-type: none"> <li>• Close the Tap Water Supplying Valve at the Water Pipe, pull out the Power Plug of the Water Purifier from the Power Outlet, and request for the service.</li> <li>• When the cold parts inside the Water Purifier combines humidity, dew may form in the same principle as water drops form on a cup with water.</li> </ul>

ENG

## Product Specification

<b>Product Name</b>		Electric Water Purifier			
<b>Type</b>		Half Type			
<b>Model</b>		CP-WN601HW			
<b>Rated Voltage</b>		Single Phase, 220V~ / 50Hz			
<b>Power Consumption</b>		450W (Cold : 0.6A, Hot : 350W)			
<b>Filtration Method</b>		Nano Positive Filtrating System			
<b>Filters</b>		Sediment Filter (4 months)	Pre-Carbon Block 2.0 Filter (8 months)	Natural 2.0 Filter (12 months)	Nano Positive 3.0C Filter (12 months)
<b>Capacity</b>	<b>Room Water</b>	1.0L			
	<b>Cold Water</b>	2.8L			
	<b>Hot Water</b>	1.4L			
	<b>Total Capacity</b>	5.2L			
<b>Type of Refrigerants</b>		R-134a			
<b>Climate Classification</b>		N(Temperate)			
<b>Installation Area</b>		For indoor use			
<b>Product</b>	<b>Weight</b>	14.3 kg			
	<b>Dimension (WxDxH)</b>	260x508x508 mm			
<b>Rated Working Pressure</b>		0.05MPa-0.39MPa (0.5bar-3.9bar)			

※The information (exterior, design and specifications) provided in this User Manual is subject to change without prior notice to improve the quality of the product.

## WARRANTY

**Cuckoo Appliances Private Limited** (hereinafter to be referred as “CUCKOO”) believes that your water purifier is a vital component of your life. It makes your life simple by helping you cook, save water & have drinkable water easily. Unfortunately, usual wear and tear from daily usage, along with age, can happen in appliances also malfunctions are quite common and natural if you own the appliance & that means repair or replacement is inevitable.

CUCKOO offers warranty for all its products manufactured by it and assures its users that all its products are free from defects in material and workmanship under normal usage and service from the date of purchase. Whenever a Purifier breakdowns, you can trust CUCKOO as a Service (CAAS) to connect you to a qualified, professional service Technician who will diagnose your Purifier’s malfunction and suggest repair or replacement.

1. The Warranty tenure starts from the date of installation by the first end-user as mentioned in the installation order and is valid for a period of One year thereafter and this warranty is Non - transferable.
2. During this Warranty period, CUCKOO will replace or repair the parts/accessories that in the opinion of CUCKOO or its ASP (Authorized Service Provider), would be defective in operation due to faulty material or workmanship (i.e. manufacturing defects). This warranty covers only the repairs and does not entitle the Customer for replacement of the Product. This warranty explicitly does not cover consumables (all inside filters and plastic body). However, if the filter get clogged within first six months, it shall be cleaned / repaired / replaced at no extra charge, but this is upon the investigation & inquiry by the technician and at the sole discretion of CUCKOO.
3. The Company’s liability under this warranty shall remain valid only if the products are duly installed by CUCKOO or its Authorized representatives at the location specified in the Invoice and such Installation is undertaken by the Company or its Authorized agent. The Company will put its best efforts to promptly attend to any breakdown complaint lodged by the Customer on the Customer Care of CUCKOO. The Company shall carry out repairs or replacement, whatever the case may be, if it is determined by the Company’s authorized service representative that these are manufacturing defects.
4. In order to avail services under warranty the Customer shall produce the original purchase invoice and warranty card having dealer stamp and date of purchase at the time of requesting the warranty services along with complete product together with the damaged part(s), failing which the warranty will not be honored.

## WARRANTY

ENG

5. In the event of repair of any part, during the said Warranty Period, the warranty shall thereafter continue only for the unexpired period of the original warranty Period. The defective part(s) shall become property of CUCKOO. The Company reserves the right to decide at its discretion, for replacing any defective part with a substitute without affecting the performance of the Product.
6. This warranty shall not apply with respect to the Products or any part thereof which has been subject to Installation/repair by any unauthorized persons or repair/use of this Product or any accessories other than those specified by Company; any accident or damage during transit; mishandling, dust, unauthorized modifications, precipitates or biological growth, input voltage beyond specifications, riots, commercial use, lightning, use contrary to the operations specified in the user's manual supplied with the Product/unit, alteration; Unit/part(s) Serial No. mutilated, defaced or altered; Fire; Flood or such occurrences; water, Presence of any foreign object or living creature (e.g. Rat, lizard, insect, ants, etc.) inside the Product unit; use of harmful chemicals; Improper heat load, Usage of unit in an abnormally corrosive alkaline/acidic atmosphere; Any change or defect resulting due to improper maintenance.
7. Outer body of the product is not covered under Warranty and hence, it must be handled with care to guard against breakage. Any such damage shall be chargeable as per the company policy.
8. This Warranty is null and void if the unit is operated/fed with water other than Municipal Corporation or with well water conditions or is subjected to the temperature above 40°C.
9. Product returned to CUCKOO or its ASP for Warranty examination must be shipped freight prepaid to the Authorized Service Centre. This warranty does not cover cost of labor, transportation cost of the Product from the place of installation to the Authorized service center and other incidental expenditures, these shall be borne by the Customer.
10. This Warranty Agreement shall not be interpreted to render CUCKOO or its ASP liable for injuries or damages of any kind -direct/indirect, consequential or contingent to persons or property.
11. CUCKOO or its ASP shall not be held liable for repair or alterations made without prior written approval; for products clogged by suspended matter, precipitates or biological growth; or for failures resulting from the lack of proper maintenance.
12. The Company shall not be liable or be deemed to be in default for any delay or failure in performance resulting directly or indirectly from causes beyond its reasonable control including delay in repairing due to non-availability of any component or accessory, labor problem, restrictions and regulations of the government, public movement, war and any unavoidable circumstances, specially vis-à-vis the import of supplies, sickness / illness due to consumption of drinking water from improperly maintained purifier, and raw material or if the Company is otherwise prevented from performing its functions under this warranty.
13. This Warranty Agreement excludes all products/component parts or damage to any part of this water purifier which, in the opinion of CUCKOO or its ASP have been subjected to misuse; misapplication; negligence; alteration; accident or operation contrary to instructions, incompatibility with accessories not installed by CUCKOO or its ASP, or that have been repaired with component parts other than those manufactured by or obtained from CUCKOO or its ASP. Damage caused by freezing, flood, fire or Act of God is not covered by this Warranty. In all such cases regular charges will apply. Furthermore, the warranty in no case shall extend to the payment of any monetary consideration whatsoever or the replacement or return of the Product as a whole.
14. While the Company will make every effort to carry out repairs at the earliest, it is however made explicitly clear that the Company is under no obligation to do so in a specified period of time.
15. CUCKOO reserves the right to alter or improve design and specifications at any time, without any contingent obligations to prospective buyers or owners of the products previously sold.
16. Any disagreements/disputes arising out of the purchase of CUCKOO products and shall be governed by and construed according to the laws of India and subject to the Jurisdiction of New Delhi Courts only.
17. CUCKOO or its ASP accepts no Warranty liability in connection with this water purifier other than that specified herein. This Warranty is in lieu of all other warranties, expressed or implied, including warranties of fitness for a particular purpose. CUCKOO or its ASP does not approve any person or representatives to assume for them any other obligations on the sale of this water purifier. The Company's obligation under this warranty shall be limited to repair of part/s only. The maximum amount of liability with respect to any Product related claim/s, if entertained by Company, will be subject to the maximum retail price of the Product purchased or the purchase price, whichever is lower.
18. In case of any challenge faced in operating the Purifier, customer needs to call CUCKOO Customer Care for any type of Assistance.
19. In case of change of Customer's Residence, Customer has to inform us within 15 days of location change for on-time Services. No legal claim or obligation will fall on the Company on account of the product not being compatible with the changed location. Any and all additional costs for changing or up gradation of the product will be borne by the customer only.
20. CUCKOO or its ASP cannot and shall not be held liable for any sickness or illness due to the consumption or drinking water from any water purifier supplied by CUCKOO, since CUCKOO or its ASP does not have any control over the maintenance and usage of water purifier.
21. CUCKOO reserves the right to alter or improve design and specifications at any time, without any contingent obligations to prospective buyers or owners of the products previously sold.
22. CUCKOO or its ASP assumes no warranty liability in connection with this water purifier other than that specified herein. This Warranty is in lieu of all other warranties, expressed or implied, including warranties of fitness for a particular purpose. CUCKOO or its ASP does not authorize any person or representative to assume for them any other obligation on the sale of this water purifier.
23. Under no circumstances, the liability of CUCKOO or its ASP shall exceed the value of the product.
24. All the decisions regarding repair/replace of Filter or any Parts are subject to discretion of CUCKOO.
25. All and any of the spare parts/accessories of the product can be of a brand/supplier as internally decide by Cuckoo Appliances Private Limited from time to time. Any change will not amount to any legal or otherwise claim against the Company, and shall be subject to the discretion of CUCKOO.
26. Post-warranty the customer may avail the Extended warranty Scheme if it is applicable on the purchase of the product at the prevailing company rates and terms.

## เรียน ลูกค้าทุกท่าน

### ขอขอบคุณที่ซื้อ เครื่องกรองน้ำระบบร้อน-เย็น ยี่ห้อ CUCKOO

กรุณาเก็บคู่มือผู้ใช้งานนี้ (รวมถึงใบรับประกัน) ไว้เพื่อใช้อ้างอิง  
คู่มือนี้จะช่วยแนะนำคุณเกี่ยวกับวิธีใช้งานและเมื่อฟังก์ชันทำงาน  
ไม่ถูกต้อง



#### คุณสมบัติของผลิตภัณฑ์

- ระบบการกรองแบบ 4 กระจบอง  
ระบบการกรอง 4 กระจบองของเครื่องกรองน้ำ CUCKOO  
ทำให้มีรสชาติและดีต่อสุขภาพโดยประกอบด้วยแร่ธาตุต่าง ๆ
- ถังน้ำสเตนเลส  
วัสดุของถังเก็บน้ำผลิตจากสเตนเลส  
เพื่ยกระดับความสะอาดของกระบวนการกรองน้ำและภายในถังน้ำมากขึ้น
- ระบบกรองน้ำที่ประหยัดและเป็นมิตรกับสิ่งแวดล้อม  
เราได้เลือกใช้ระบบกรองน้ำที่ประหยัดและเป็นมิตรต่อสิ่งแวดล้อม  
โดยที่ไม่มีการสูญเสียน้ำเกิดขึ้นระหว่างกระบวนการกรองน้ำการใช้ไส้กรอง Nano Positive (นาโนประจุบวก)
- ก๊อกน้ำด้านนอก (อุปกรณ์เสริม)  
ติดตั้งก๊อกน้ำในครัว เพื่อใช้น้ำที่กรองแล้วในครัวได้เช่นกัน
- ไฟแสดงสถานะการทำงาน  
สะดวกสบายเนื่องจากรู้สถานะการทำงานของผลิตภัณฑ์ ด้วยไฟแสดงการทำงานน้ำร้อน, น้ำเย็น และฆ่าเชื้อได้ในพริบตา
- ปุ่มเซฟตี้สำหรับน้ำร้อน  
เวลาใช้น้ำร้อน จะใช้ปุ่มเซฟตี้น้ำร้อนแยกต่างหาก เพื่อป้องกันอันตรายจากน้ำร้อนลวกเวลาเด็ก ๆ ใช้
- ดีไซน์สวยงาม  
ประหยัดพื้นที่เป็นเลิศและเข้าได้กับทุกสถานที่ด้วยดีไซน์ที่เล็กบางและสวยงาม
- ใช้สวิตช์ไฟน้ำร้อนและน้ำเย็นแยกจากกัน โดยสิ้นเชิง  
ช่วยประหยัดไฟเนื่องจากสามารถ On (เปิด) และ Off (ปิด) ไฟน้ำร้อนและไฟน้ำเย็นแยกกันได้
- ระบบการฆ่าเชื้อก๊อกน้ำ (เฉพาะรุ่น)  
สามารถใช้เครื่องกรองน้ำที่ถูกต้องตามหลักขณะ ผ่านการฆ่าเชื้อหัวจ่ายน้ำด้วยถ้วยฆ่าเชื้อ

## สารบัญ

ก่อนเริ่มการใช้งาน	• คำเตือนเพื่อการใช้งานอย่างปลอดภัย	32 ~ 35
	• ข้อควรระวังเพื่อการใช้งานอย่างปลอดภัย	36
	• ชื่อของชิ้นส่วน / ข้อมูลเกี่ยวกับส่วนประกอบ	37
วิธีการใช้งาน	• แผนผังการวางท่อกรองน้ำ / ระบบการบำบัดน้ำ	38
	• รายละเอียดที่ต้องตรวจสอบก่อนการติดตั้ง	39
	• วิธีติดตั้งผลิตภัณฑ์	40
	• รายละเอียดที่ต้องตรวจสอบก่อนใช้งาน	41
	• รายละเอียดที่ต้องตรวจสอบก่อนใช้งาน / วิธีการใช้งาน	42
	• วิธีใช้งาน / วิธีใช้งานการฆ่าเชื้อก๊อก	43
	• วิธีใช้งานการฆ่าเชื้อก๊อก	44
	• วิธีการตรวจสอบฟังก์ชันการแจ้งเตือนการเปลี่ยนไส้กรอง	45
	• วิธีการทำความสะอาดถังน้ำเย็น	46~48
	• วิธีทำความสะอาดถาดรองน้ำ / วิธีทำความสะอาดหัวจ่าย	49
	• วิธีการเปลี่ยนไส้กรอง	50~52
	• ระยะเวลาในการเปลี่ยนไส้กรอง / คำแนะนำ / ลำดับในการใส่ไส้กรอง	53
ก่อนติดต่อฝ่ายบริการ	• ติดต่อฝ่ายบริการ	54~55
คู่มือการให้บริการ	• ข้อกำหนดของผลิตภัณฑ์	56
	• การรับประกัน	56~57
	MEMO	58~59



## คำเตือนเพื่อการใช้งานอย่างปลอดภัย

- โปรดปฏิบัติตาม 'คำเตือนเพื่อการใช้งานอย่างปลอดภัย' ตามที่ให้ไว้เพื่อให้แน่ใจว่าการใช้งานอุปกรณ์เป็นไปอย่างปลอดภัยและเหมาะสมและป้องกันอุบัติเหตุและสถานการณ์ที่เป็นอันตราย
- หัวข้อ 'คำเตือนเพื่อการใช้งานอย่างปลอดภัย' ถูกแบ่งออกเป็น 'คำเตือน' และ 'ข้อควรระวัง' โดยมีคำจำกัดความดังนี้

	<b>คำเตือน</b>
บ่งบอกถึงคำเตือนว่าควรหลีกเลี่ยง ในกรณีที่เจอ สถานการณ์ที่อาจเป็นอันตราย ซึ่งอาจทำให้ได้รับบาดเจ็บสาหัสหรือเสียชีวิต	
	<b>ข้อควรระวัง</b>
บ่งบอกถึงข้อควรระวังว่าควรหลีกเลี่ยง ในกรณีที่เจอสถานการณ์ที่อาจเป็นอันตราย ซึ่งอาจทำให้ได้รับบาดเจ็บเล็กน้อย	
	<ul style="list-style-type: none"> <li>• สัญลักษณ์นี้แสดงถึงสถานการณ์ที่อาจเป็นอันตรายภายใต้สถานการณ์พิเศษ</li> <li>• โปรดอ่านรายละเอียดอย่างละเอียดและปฏิบัติตามคำแนะนำเพื่อหลีกเลี่ยงสถานการณ์ที่เป็นอันตราย</li> </ul>
	<ul style="list-style-type: none"> <li>• สัญลักษณ์นี้ใช้เพื่อบูการกระทำที่เป็นข้อห้าม</li> </ul>
	<ul style="list-style-type: none"> <li>• สัญลักษณ์นี้ใช้เพื่อบูการกระทำที่เป็น 'คำสั่ง'</li> </ul>

## เกี่ยวกับไฟฟ้า

	<b>คำเตือน</b>		<b>ห้าม</b>
<p>เสียบปลั๊กไฟเข้ากับตัวรับ 220V~ ที่มีอัตรากระแสไฟฟ้าอย่างน้อย 10A และมีระบบป้องกันไฟกระชาก</p> <p>ห้ามต่ออุปกรณ์หลายเครื่องเข้ากับปลั๊กไฟหรือปลั๊กพ่วงเดียวกันพร้อมกัน</p>		<p>กรณีสายไฟ ปลั๊กไฟ หรือปลั๊กไฟที่หนึ่ง ชำรุดหรือหลวมให้หยุดใช้งานและติดต่อฝ่ายบริการลูกค้า</p>	
<ul style="list-style-type: none"> <li>• การต่ออุปกรณ์หลายเครื่องเข้ากับปลั๊กไฟเดียวกัน หรือการใช้ไฟเลี้ยงที่ไม่เหมาะสมกับตัวเครื่อง อาจทำให้เครื่องร้อน เกิดไฟไหม้ และ ไฟฟ้าช็อตได้</li> <li>• หากมีสิ่งแปลกปลอมหรือมีน้ำขุ่นบนปลั๊กไฟ โปรดเช็ดให้สะอาดก่อนเสียบปลั๊กไฟ</li> <li>• ใช้สายพ่วงหรือรับกระแสไฟฟ้า 10A หรือสูงกว่า</li> </ul>		<ul style="list-style-type: none"> <li>• หากเปลือกสายไฟหลุดลอกหรือบิดงอเนื่องจากความประมาทเดินลื้อ อาจก่อให้เกิดเพลิงไหม้หรือไฟฟ้าช็อตได้ โปรดตรวจสอบสถานะของสายไฟ ปลั๊ก และตัวรับเป็นประจำ</li> <li>• เพื่อป้องกันสถานการณ์อันตรายจากความเสียหายของสายไฟหรือปลั๊ก โปรดติดต่อผู้ผลิต ผู้จัดจำหน่าย หรือช่างเทคนิคที่ได้รับการรับรองเพื่อเปลี่ยนใหม่</li> <li>• เราขอแนะนำอย่างยิ่งให้ซ่อมแซมหรือเปลี่ยนชิ้นส่วนที่เสียหายที่ศูนย์บริการที่กำหนด</li> <li>• อาจทำให้เกิดไฟฟ้าช็อตหรือไฟไหม้เนื่องจากไฟฟ้าลัดวงจรได้</li> </ul>	
<p>ห้ามทำให้อายุสายไฟเสียหาย โดยการฉีกขาด หรือดึงสายไฟแรงๆ</p>		<p>ใช้ผ้าแห้งเช็ดคราบสิ่งสกปรกที่อยู่บนปลั๊กไฟออก</p>	
<ul style="list-style-type: none"> <li>• อาจทำให้เกิดไฟฟ้าช็อตหรือไฟไหม้เนื่องจากการลัดวงจร โปรดตรวจสอบสถานะของสายไฟเป็นประจำ</li> </ul>		<ul style="list-style-type: none"> <li>• อาจทำให้เกิดไฟฟ้าช็อตหรือไฟไหม้ได้โปรดตรวจสอบสถานะของปลั๊กไฟเป็นประจำ</li> </ul>	

# คำเตือนเพื่อการใช้งานอย่างปลอดภัย




## เกี่ยวกับไฟฟ้า

⚠ คำเตือน


🚫 ห้าม

ตอนดึงปลั๊กไฟ อย่าจับที่สายไฟให้จับที่ปลั๊กไฟแล้วดึงออก




- หากสายไฟได้รับความกระทบกระเทือน อาจจะทำให้ไฟดูดและไฟไหม้ กรุณาตรวจสอบสภาพของปลั๊กไฟและสายไฟเป็นประจำ

ห้ามใช้ไฟฟ้ากระแสสลับนอกเหนือจาก 220V~




- อาจเป็นสาเหตุทำให้เกิดไฟดูดและไฟไหม้ได้
- ผลิตภัณฑ์ทำงานผิดปกติ
- กรุณาตรวจสอบสภาพของปลั๊กไฟและสายไฟเป็นประจำ

เวลานำเข้าและทำความสะอาดกรุณาดึงปลั๊กไฟทุกครั้ง




- อาจทำให้เกิดไฟฟ้าช็อตหรือการทำงานผิดปกติได้ โปรดตรวจสอบสถานะของสายไฟและปลั๊กไฟเป็นประจำ

ตอนเสียบหรือดึงปลั๊กไฟตรงตัวรับการฉีกมือให้ห่างก่อนจับปลั๊กไฟเพื่อเสียบหรือดึง




- หากดึงปลั๊กไฟทั้งที่มีมือเปียกอาจเป็นสาเหตุให้เกิดไฟดูดได้
- หากดึงแรงเกินไปจะทำให้สายไฟฉีกขาดและอาจทำให้เกิดไฟรั่วและไฟดูด กรุณาตรวจสอบสภาพของปลั๊กไฟและสายไฟเป็นประจำ

กรุณาระมัดระวังเพื่อไม่ให้สายไฟโดนของหนักกดทับหรือของมีคมและข่าวด เพราะฉัตวเสี่ยง




- สายไฟข่าวดเป็นสาเหตุของไฟดูดและไฟไหม้ กรุณาตรวจสอบสภาพของสายไฟเป็นประจำ

กรณีที่มีน้ำเข้าบางส่วนของแหล่งไฟฟ้าให้ดึงปลั๊กไฟออกและทำให้แห้งก่อนใช้งาน




- อาจเป็นสาเหตุทำให้เกิดไฟดูดและไฟไหม้ได้ กรุณาตรวจสอบสภาพของปลั๊กไฟและสายไฟเป็นประจำ

กรุณาเปิดไฟที่ปม POWER เท่านั้น และกรุณาดึงปลั๊กไฟออกในระหว่างการซ่อมแซม หรือตรวจสอบและเปลี่ยนอะไหล่ทุกครั้ง



- มีความเสี่ยงที่เครื่องจะเสียหายหรือไฟดูด กรุณาตรวจสอบสภาพของปลั๊กไฟและสายไฟเป็นประจำ

เวลาไม่ได้ใช้งานเป็นเวลานานหลังจากปิดตัวจำหน่ายและดึงปลั๊กไฟแล้วกรุณาระบายน้ำออกทั้งหมด



- อาจเป็นสาเหตุทำให้เกิดไฟดูด และไฟไหม้ได้ กรุณาตรวจสอบสภาพของปลั๊กไฟและสายไฟเป็นประจำ
- กรุณาอ้างอิง “รายการตรวจสอบก่อนใช้งาน” เวลากลับมาใช้งานอีกครั้ง

THA



## คำเตือนเพื่อการใช้งานอย่างปลอดภัย

### เกี่ยวกับการติดตั้ง



คำเตือน




ห้าม

ห้ามติดตั้งในที่ที่มีความชื้น และมีฝุ่นมาก



- อาจเป็นสาเหตุทำให้เกิดไฟดูด และ ไฟไหม้ได้


ห้ามติดตั้งในสถานที่ที่ใกล้กับห้องน้ำ



ห้ามติดตั้งผลิตภัณฑ์บนพื้นที่ขรุขระและลาดเอียง หรือ บนพาเลท, ภาชนะรองน้ำ และ พื้นห้องปูเสื่อน้ำนั้น


- อาจเป็นสาเหตุทำให้เครื่องสั่น และเกิดเสียงดังได้ รวมถึง ได้รับบาดเจ็บ การนำตรวจสอบสภาพผลิตภัณฑ์เป็นประจำ
- ผลิตภัณฑ์นี้ ใช้งานได้กับรูปแบบของผลิตภัณฑ์

ห้ามติดตั้งผลิตภัณฑ์ในที่ที่มีแสงแดดส่องโดยตรง และหลีกเลี่ยงที่มีอุณหภูมิสูง



- อาจเป็นสาเหตุทำให้เกิดการเปลี่ยนสีและสึกได้
- กรุณา ตรวจสอบสภาพของสายไฟเป็นประจำ

อุปกรณ์นี้ไม่ได้ผลิตมาเพื่อใช้กับบุคคลที่บกพร่องทางร่างกาย (รวมถึงเด็ก), ประสาทสัมผัส, จิตใจหรือขาดประสบการณ์และความรู้ และคนที่ไม่สามารถใช้อุปกรณ์นี้ได้ โดยไร้การควบคุมหรือชี้แนะอย่างปลอดภัย




- กรุณาระมัดระวังไม่ให้เด็กเข้าไปเล่นกับอุปกรณ์

กรุณาติดตั้งสายจ่ายน้ำดิบที่ต่อกับผลิตภัณฑ์ให้ห่างจากกาวล้วยน้ำไม่เกิน 5 เมตร




- อาจเป็นสาเหตุทำให้ประสิทธิภาพของผลิตภัณฑ์เสื่อมลง

ห้ามติดตั้งผลิตภัณฑ์ในที่ที่แก๊สรั่วไหลได้ หรืออยู่ใกล้กับเครื่องปรับอากาศ



- มีความเสี่ยงที่เครื่องจะระเบิดหรือไฟดูด

น้ำดิบต้องเป็นน้ำประปาเท่านั้นและกรุณาติดตั้งแล้วจ่ายน้ำดิบเอาไว้ฝั่งท่อน้ำเย็น



- ห้ามใช้น้ำดิบที่ไม่ใช่ประปา เช่น น้ำบาดาล
- ครอบเปลี่ยนเฟลเตอร์ อาจแตกต่างกันได้ขึ้นตามแต่ละพื้นที่และปริมาณการใช้น้ำ
- อาจเป็นสาเหตุทำให้เฟลเตอร์ชำรุดและเครื่องเสียงตอนติดตั้งบนท่อน้ำร้อน

กรุณาติดตั้งโดยหลีกเลี่ยงสถานที่หรือภายนอกอาคารที่อุณหภูมิต่ำกว่า 0 °C



- ใส่อุปกรณ์และภายในผลิตภัณฑ์กลายเป็นน้ำแข็ง เป็นสาเหตุทำให้เครื่องเสียงและน้ำรั่ว

อาจเกิดการที่มีอุณหภูมิโดยรอบต่ำกว่า 0 °C ช่วงฤดูหนาวและภายในใส่อุปกรณ์และเครื่องกรองน้ำเสียหายเพราะน้ำในท่อเป็นน้ำแข็ง ดังนั้น กรุณาระมัดระวังไม่ให้อุณหภูมิโดยรอบสถานที่ติดตั้งผลิตภัณฑ์ต่ำกว่า 0 °C

- กรณีที่ไม่สามารถจ่ายน้ำได้เนื่องจากน้ำกลายเป็นน้ำแข็งเพราะอุณหภูมิโดยรอบต่ำกว่า 0 °C กรุณาปิดน้ำร้อนเพื่อความปลอดภัย




## คำเตือนเพื่อการใช้งานอย่างปลอดภัย



### ⚠ คำเตือน


### 🚫 ห้าม

ห้ามวางหรือใช้เครื่องใช้ไฟฟ้า เช่น เต้าไมโครเวฟ, เต้าไฟฟ้า, เครื่องปิ้งขนมปัง บนผลิตภัณฑ์ และห้ามวางวัตถุไวไฟ เช่น เทียน, ถังแก๊ส, ไฟแช็ก ฯลฯ บนผลิตภัณฑ์



- เสียงทำให้เกิดอันตรายด้านความปลอดภัย เช่น ไฟไหม้ และ ไฟดูดได้

ตอนเคลื่อนย้ายผลิตภัณฑ์ กรุณาอย่าดึงสายไฟ และสายยางเชื่อมต่อ หรือจับบริเวณก๊อก




- เป็นสาเหตุทำให้ผลิตภัณฑ์ชำรุด กรุณาตรวจสอบสภาพของสายไฟเป็นประจำ

ระหว่างใช้ผลิตภัณฑ์ คอนเดนเซอร์ (คอยล์ร้อน) ด้านหลังผลิตภัณฑ์เกิดความร้อนและบวม เพื่อป้องกันอุบัติเหตุด้านความปลอดภัย กรุณาระมัดระวังไม่ให้มือหรืออวัยวะบนร่างกายสัมผัส

- เป็นสาเหตุของบาดแผลและ อุบัติเหตุด้านความปลอดภัย

ห้ามวางยา, ถังน้ำ และชิ้นส่วนโลหะเล็กๆ ด้านบนผลิตภัณฑ์



- ผลิตภัณฑ์อาจเสียหายทำให้เกิด ไฟไหม้และผลิตภัณฑ์ชำรุดได้

ห้ามถอดชิ้นส่วนหรือประกอบผลิตภัณฑ์เอง



- อาจเกิดไฟไหม้และไฟดูด
- อาจถอดชิ้นส่วน หรือทิ้ง หากไม่ใช่ช่างศูนย์บริการ
- ต้องการซ่อมแซม หรือเครื่องเสียหาย กรุณาติดต่อ ฝ่ายบริการลูกค้า


อย่ากดปุ่มน้ำร้อนและเย็นในขณะที่ถังน้ำไม่มีน้ำ

- บริษัทจะไม่รับผิดชอบต่อความเสียหายที่เกิดจากการไม่ปฏิบัติตามรายการด้านล่าง ซึ่งเป็นสาเหตุให้ผลิตภัณฑ์เสียหาย
- กรุณาตรวจสอบว่ามีน้ำหรืออาจล้นน้ำจากถังน้ำร้อนหรือเย็น และอย่ากดปุ่มเปิดน้ำร้อนและเย็น ขณะที่ไม่มีน้ำอยู่ในถัง หลังจากเติมน้ำให้เต็มถึง กรุณาปิดปุ่มเปิดน้ำร้อนและเย็น
- กรณีที่กดปุ่มน้ำร้อนขณะที่ไม่มีน้ำอยู่ในถังน้ำร้อน อุปกรณ์รักษาความปลอดภัยจะทำงาน โดยซีตเตอร์น้ำร้อนจะ ไม่ร้อน และน้ำอาจจะออกมาแทนเพื่อความปลอดภัย หากเกิดเหตุเช่นนี้ กรุณาติดต่อฝ่ายบริการลูกค้า

### ⚠ คำเตือน

### ! ชี้นะ

หากมีน้ำรั่วไหลออกมาจากผลิตภัณฑ์ หรือน้ำไหลออกมาบริเวณรอบๆ กรุณาถอดปลั๊กสายน้ำ, กดปุ่มปิดเครื่อง ดึงปลั๊กออก และติดต่อฝ่ายบริการลูกค้า




- มีความเสี่ยงที่จะไฟดูด

การาระมัดระวังตอนใช้น้ำร้อน




- น้ำร้อน มีความร้อนสูงมาก เสียงที่จะเกิดอาจขาดเจ็บ กรุณาอย่าใช้มือสัมผัส และระมัดระวังไม่ให้ผู้สูงอายุ และเด็กใช้งาน

ตอนเปลี่ยนไส้กรอง กรุณาถอดปลั๊กสายน้ำ (ปกติแล้ววาล์วจ่ายน้ำจะอยู่ที่ใต้อ่างล้างจานหรือก๊อกน้ำ)



- เป็นสาเหตุของน้ำรั่ว


ถ้าได้กลิ่นใหม่ หรือมีควันไฟออกมาจากผลิตภัณฑ์ กรุณาดึงปลั๊กออก ลือดวาล์วจ่ายน้ำ และติดต่อฝ่ายบริการลูกค้า



- มีความเสี่ยงที่จะเกิดไฟไหม้

ตอนติดตั้งหรือถอนการติดตั้งผลิตภัณฑ์ กรุณาให้ช่างบริการติดตั้งหรือถอนการติดตั้งผ่านศูนย์บริการ

อาจก่อให้เกิดไฟไหม้หรือการเปลี่ยนแปลงของผลิตภัณฑ์



- รักษาระยะห่างจากผนัง 20 ซม.




## ข้อควรระวังเพื่อการใช้งานอย่างปลอดภัย

### ⚠️ ข้อควรระวัง

### ❗ ขี้แฉะ

กรุณาใช้งานหลังจากเปิดฝาดังนํากายในผลิตภัณฑ์และเปิดฝาด้านบนผลิตภัณฑ์จนสนิททั้งหมดแล้ว

- อาจมีสิ่งแปลกปลอมเข้าไปได้




กรุณาเปลี่ยนไส้กรองตามรอบการเปลี่ยนไส้กรอง

- อาจเป็นสาเหตุทำให้คุณภาพของน้ำกรองลดลงและเกิดกลิ่น
- รอบการเปลี่ยนฟิลเตอร์ กรุณาอ้างอิงที่หน้า 52



กรณีที่ไม่ได้ใช้งานเป็นเวลานาน กรุณาระบายน้ำภายในถึงน้ำออกจนหมด เติมน้ำใหม่จนเต็ม และระบายน้ำทิ้งอีกครั้งก่อนใช้งาน

- เมื่อระบายน้ำในถึงน้ำเย็นออกมา จะได้น้ำ 3.8 ลิตร
- ถ้าระบายน้ำร้อนก่อนระบายน้ำเย็น เครื่องแบบตั้งพื้นจะได้น้ำ 3.5 ลิตร ส่วนเครื่องแบบตั้งโต๊ะจะได้น้ำ 2.4 ลิตร กรุณาระบายน้ำเย็นก่อนระบายน้ำร้อน



กรุณาใช้ไส้กรองของบริษัท CUCKOO เท่านั้น

- เมื่อใช้ไส้กรองที่ไม่ใช่ของบริษัท CUCKOO คุณภาพของน้ำกรองอาจลดลง รสชาติของน้ำผิดปกติ และทำให้เกิดน้ำรั่วและผลิตภัณฑ์เสียหายได้

กรณีที่ไม่ได้ใช้นานกว่า 1 วัน หากกลับมาใช้น้ำอีกครั้ง กรุณาระบายน้ำทิ้งประมาณ 1-2 นาที ก่อนใช้งาน

ห้ามใช้น้ำจากเครื่องกรองน้ำเปลี่ยนน้ำในอ่างล้างจานหรือตู้ปลา

- น้ำที่กรองแล้วอาจจะไม่เข้ากับสภาพแวดล้อมของปลาปลาอาจตายได้ในกรณีนี้


- \* นํายาฆ่าเชื้อ ไม่ใช่สำหรับดื่ม นํายาฆ่าเชื้อ ไม่ใช่สำหรับดื่ม กรุณาระมัดระวัง
- \* กรุณาทำความสะอาดด้วยนํายาฆ่าเชื้อ สำหรับล้างผักและผลไม้, เครื่องใช้ต่าง ๆ และล้างโดยใช้น้ำอุ่นล้างจาน
- \* หลังจากนํายาฆ่าเชื้อไหลออกมาหมดแล้ว อาจมีนํายาฆ่าเชื้อหลงเหลือที่วาล์วนําน้ำในครีวดังนั้น หลังจากใช้นํายาฆ่าเชื้อแล้ว

### ⚠️ ข้อควรระวัง

### 🚫 ห้าม


ห้ามใช้ทินเนอร์หรือเบนซินทำความสะอาดผลิตภัณฑ์

- มีความเสี่ยงที่จะทำให้ผลิตภัณฑ์เสียหาย




อย่าเคลื่อนย้ายผลิตภัณฑ์ระหว่างที่เครื่องกำลังทำงาน

- อย่าเคลื่อนย้ายหรือเขย่าผลิตภัณฑ์ในขณะที่เสียบปลั๊กอยู่ เป็นสาเหตุทำให้ผลิตภัณฑ์เสียหายและน้ำรั่ว เนื่องจากสายน้ำเชื่อมต่อนหลุด



อย่าดึงสายน้ำด้านหลังผลิตภัณฑ์ระหว่างใช้ผลิตภัณฑ์


- เป็นสาเหตุที่ทำให้เสียหายเนื่องจากน้ำรั่ว





## ชื่อของชิ้นส่วน / ข้อมูลเกี่ยวกับส่วนประกอบ

### ชื่อของชิ้นส่วน



THA

### ข้อมูลอะไหล่



คู่มืออธิบายการใช้งาน



ใบรับประกัน



ก๊อกน้ำ (อุปกรณ์เสริม)




กระบอกสำหรับใช้ฆ่าเชื้อที่หัวจ่ายน้ำ




## แผนผังการวางท่อกรองน้ำ / ระบบการบำบัดน้ำ

### แผนผังการวางท่อกรองน้ำ



### Filtration System



Steps	Filter Name	Filter Function
ลำดับที่ 1	ไส้กรอง SEDIMENT	กำจัดคราบตะกอน สนิมและอนุภาคต่างๆ
ลำดับที่ 2	ไส้กรอง PRE-CARBON BLOCK 2.0	ช่วยกำจัดคลอรีน สารอินทรีย์และกลิ่นไม่พึงประสงค์
ลำดับที่ 3	ไส้กรอง NATURAL 2.0	ช่วยกำจัดคลอรีน สารอินทรีย์และกลิ่นไม่พึงประสงค์ ช่วยฆ่าเชื้อและเพิ่มแร่ธาตุในน้ำ
ลำดับที่ 4	ไส้กรอง NANO POSITIVE 3.0C	กำจัดอนุภาคเล็กมาก, จุลินทรีย์, ไวรัส และโลหะหนัก (ตะกั่ว, เหล็ก, โครเมียม, อะลูมิเนียม)

\* หากใช้ฟิลเตอร์ที่ไม่ใช่ของแท้ หรือใช้ฟิลเตอร์ของแท้นานเกินไป อาจจะทำให้คุณภาพของฟิลเตอร์เสื่อม



## รายละเอียดที่ต้องตรวจสอบก่อนการติดตั้ง



### ข้อควรตรวจสอบก่อนการติดตั้ง

#### ⚠ ข้อควรระวังของสถานที่ที่ติดตั้ง

- 1 หลีกเลี่ยงสถานที่ที่แสงแดดส่องโดยตรง และหลีกเลี่ยงเครื่องใช้ไฟฟ้า  
▶จะทำให้เกิดไฟไหม้และผลิตภัณฑ์เปลี่ยนสี
- 2 เว้นระยะพื้นที่ติดตั้ง  
▶เว้นระยะห่างจากกำแพง 20 ซม. ขึ้นไป โดยพิจารณาจากความสะดวกสบายในการเปลี่ยนไส้กรอง ติดตั้งสายน้ำจ่ายน้ำดื่มในพื้นที่ที่สายมีความยาวห่างจากสายน้ำไม่เกิน 5 เมตร
- 3 หลีกเลี่ยงสถานที่ที่มีความชื้นและมีฝุ่นมาก และสถานที่ที่นำกระเด็นโดน ได้โดยตรง  
▶เป็นสาเหตุที่ทำให้ผลิตภัณฑ์เสียหาย
- 4 หลีกเลี่ยงสถานที่ขรุขระ ลาดเอียง และไม่แข็งแรง  
▶จะทำให้เกิดไฟไหม้และผลิตภัณฑ์ชำรุด
- 5 หลีกเลี่ยงสถานที่ที่อุณหภูมิต่ำกว่า 0 °C  
▶หากติดตั้งผลิตภัณฑ์ภายในอาคารสถานที่ที่อุณหภูมิต่ำกว่า 0 °C จะทำให้ไส้กรองและภายในผลิตภัณฑ์เป็นน้ำแข็ง เกิดความเสียหายและนำรั่วไหลได้




#### ⚠ ข้อควรระวังเวลาเคลื่อนย้ายตำแหน่ง

- 1 โปรดใช้ความระมัดระวังในการเคลื่อนย้ายเครื่อง  
▶ห้ามเอียงเครื่องในมุมเกิน 45°ให้ร่อนอย่างน้อย 30 นาที ก่อนเสียบสายไฟหลังจากเคลื่อนย้ายเครื่อง



#### ⚠ ข้อควรระวังเวลาเชื่อมต่อท่อ


- 1 กรุณาเชื่อมต่อกับท่อน้ำเย็น  
▶กรณีที่เชื่อมต่อกับท่อน้ำร้อน อาจทำให้ไส้กรองชำรุดหรือเครื่องเสียหายได้  
▶วิธีเชื่อมต่อสายยาง กรุณาอ้างอิงตามวิธีติดตั้งผลิตภัณฑ์ (หน้า 40)



\* เลี่ยงการวางอาคารแรง ขึ้นอยู่กับสถานที่ติดตั้ง กรุณาตรวจสอบว่าสถานที่ติดตั้งมีการสิ้นเสี้ยนหรือไหม



## วิธีติดตั้งผลิตภัณฑ์



### 1 เชื่อมต่อวาล์วจ่ายน้ำประปาเข้ากับท่อน้ำเย็น

\* ข้อควรระวัง

- ติดตั้งวาล์วน้ำประปาที่จ่ายน้ำเข้าเครื่องในตำแหน่งปิด
- วาล์วน้ำประปาที่จ่ายน้ำเข้าเครื่องจะต่อมาจากท่อน้ำเย็นเท่านั้น หากติดตั้งที่ท่อน้ำร้อน อาจทำให้ไส้กรองหรือตัวเครื่องเสียหาย

### 2 เชื่อมต่อท่อจ่ายน้ำประปาเข้ากับข้อต่อก๊อกน้ำที่ด้านหลังเครื่อง

\* ข้อควรระวัง

- ต่อเข้ากับตำแหน่งที่ถูกต้องของข้อต่อก๊อกน้ำ (กดจนกว่ามีเสียงคลิก)
- เชื่อมต่อท่อนอกเมื่อคุณติดตั้งวาล์วภายนอก (อุปกรณ์เสริม)

### 3 หมุนเปิดวาล์วจ่ายน้ำดิบ

### 4 เสียบปลั๊กไฟลงในเต้ารับ

### 5 หลังจากติดตั้งเสร็จเรียบร้อย ให้ตรวจสอบว่ามีน้ำรั่วในรอยรั่วบริเวณจุดต่อของท่อหรือไม่

- วาล์วจ่ายน้ำประปา (ชุดท่อ)
- ก๊อกภายนอก (ช่องออกภายนอก)
- ข้อต่อก๊อกน้ำ
- ข้อต่อไส้กรอง

ใช้น้ำประปาเป็นแหล่งจ่ายน้ำ  
\* ห้ามใช้น้ำบาดาลหรือน้ำจากแหล่งอื่นเป็นแหล่งจ่ายน้ำ

## รายละเอียดที่ต้องตรวจสอบก่อนใช้งาน



### ข้อควรระวัง


ห้ามเปิดสวิตช์น้ำร้อนและเย็นตอนที่ไม่มีน้ำในถัง(เป็นสาเหตุทำให้ผลิตภัณฑ์เสียหาย)

- หลังจากเติมน้ำให้เต็มถัง กรุณาปิดฝาเปิดน้ำร้อนและเย็น
- กรณีที่กดปุ่ม POWER ขณะที่ไม่มีย้ำอยู่ในถังน้ำ อุปกรณ์รักษาความปลอดภัยจะทำงาน โดยสวิตเตอร์ น้ำร้อนจะไม่ร้อน และน้ำอุ่นจะออกมาแทนเพื่อความปลอดภัย หากเกิดเหตุเช่นนี้ กรุณาติดต่อฝ่ายบริการลูกค้า
- กรุณาตรวจสอบว่าการเติมน้ำหรือว่าน้ำล้นจากถังล้นอยู่หรือไม่ และอย่ากดปุ่มเปิดน้ำร้อนและเย็นขณะที่ไม่มีน้ำอยู่ในถัง

## รายละเอียดที่ต้องตรวจสอบก่อนใช้งาน


### 1 เปิดวาล์วจ่ายน้ำ

- ▶ ก่อนอื่น ตรวจสอบว่าวาล์วน้ำประปาเปิดอยู่ หลังจากนั้นให้เปิดวาล์วจ่ายน้ำดื่ม




### 2 หมนคันโยกล็อกประตูที่ด้านขวาของผลิตภัณฑ์ไปที่คำว่า CLOSE

- ▶ นำจะถูกจ่ายน้ำที่เครื่องกรองน้ำแล้ว



### 3 เชื่อมต่อไฟฟ้า



- ▶ ผลิตภัณฑ์นี้ ใช้ไฟ 220 วัตต์, 60Hz กรุณาเชื่อมต่อตัวรับที่ถูกต้องเท่านั้น
- ▶ ตรวจสอบข้อต่อระบบน้ำ ก่อนเสียบปลั๊กไฟ
- ▶ ก่อนเชื่อมต่อไฟฟ้า กรุณาตรวจสอบให้แน่ใจว่าปุ่มน้ำเย็นและน้ำร้อนเปิดอยู่แล้วจึงเชื่อมต่อ ไฟฟ้า



### 4 เปิดสวิตช์น้ำร้อนและสวิตช์น้ำเย็น

- ▶ หากจะใช้น้ำร้อน ให้เปิดสวิตช์น้ำร้อน, หากจะใช้น้ำเย็น ให้เปิดสวิตช์น้ำเย็น ไฟแสดงสถานะดังกล่าวจะแสดงขึ้นมา

รุ่น	ไฟแสดงน้ำร้อน	ไฟแสดงน้ำเย็น
CP-WN601HW	สีแดง	สีฟ้า



- 5 กรณีที่ไม่ได้ใช้งานเป็นเวลานาน หรือติดตั้งใหม่ กรุณาระบายน้ำภายในถังน้ำออกจนหมด เติมน้ำใหม่จนเต็ม และระบายน้ำทิ้งอีกครั้ง ก่อนใช้งาน หลังจากเติมน้ำเต็มถัง ให้ระบายน้ำภายในถังทิ้ง 1 ครั้งหรือมากกว่า ก่อนใช้งาน






## รายละเอียดที่ต้องตรวจสอบก่อนใช้งาน / วิธีการใช้งาน


### รายละเอียดที่ต้องตรวจสอบก่อนใช้งาน

- 6 กรณาท่อน้ำในถาดรองน้ำทิ้งเป็นระยะ



- 7 กรณาเปลี่ยนไส้กรองและดูเลตามระยะเวลาที่กำหนด


- ▶ เพื่อการคั้นน้ำสะอาดอยู่เสมอ จำเป็นต้องเปลี่ยนไส้กรอง และดูเลตามระยะเวลาที่กำหนด
- ▶ รอบการเปลี่ยนไส้กรอง กรุณาอ้างอิงที่หน้า 53



### วิธีการใช้งานน้ำร้อน

- 1 กดปุ่มเปิดน้ำร้อน ฮีตเตอร์ทำน้ำร้อนต้องใช้เวลาทำงานประมาณ 30 นาที (ไฟสีแดงติด)

- ▶ ก่อนกดปุ่มเปิดน้ำร้อน กรุณาตรวจสอบก่อนว่ามีวาล์วจ่ายน้ำดับเปิดอยู่หรือไม่ แล้วค่อยเปิดสวิตช์น้ำร้อน



- 2 ดันคันโยกน้ำร้อนเบา ๆ แล้วกดปุ่มเซฟต์น้ำร้อน

ห้ามดันคันโยกน้ำร้อนขณะที่กำลังกดปุ่มเซฟต์น้ำร้อน น้ำร้อนอาจจะกระเด็นแล้วเกิดแผลน้ำร้อนลวกได้



- 3 หลังจากดึงคันโยกน้ำร้อนขึ้นไป 90 องศาแล้ว ถัดกดปุ่มเซฟต์น้ำร้อน น้ำร้อนจะจ่ายอย่างต่อเนื่องได้

หลังจากจ่ายน้ำอย่างต่อเนื่องแล้ว กรุณาทำให้อันโยกกลับมาอยู่ในสภาพเดิมซ้ำๆ (หากทำให้อันโยกกลับมากระพือขึ้น อาจจะเสี่ยงเกิดแผลน้ำร้อนลวก)





## วิธีใช้งาน / วิธีใช้งานการฆ่าเชื้อก๊อก




### วิธีการใช้งานน้ำเย็นและน้ำอุณหภูมิห้อง

- 1 เปิดป้อนน้ำเย็น เครื่องทำความเย็น (คอมเพรสเซอร์) ต้องใช้ระยะเวลาประมาณ 60 นาที เพื่อเริ่มต้นการใช้งาน (ไฟสีน้ำเงินสว่าง)

▶ ก่อนเปิดป้อนน้ำเย็น การตรวจสอบระบบน้ำประปาหรือวาล์วจ่ายน้ำประปาเปิดอยู่หรือไม่ แล้วค่อยเปิดสวิตช์น้ำเย็น

- 2 หมุนคันโยกเลือกไปที่ทิศทางของน้ำเย็นหรือน้ำอุณหภูมิห้อง ขึ้นอยู่กับว่าเราหมุนไปที่ทิศทางไหน น้ำเย็นหรืออุณหภูมิห้อง จะถูกจ่ายออกมา (โดยทิศทาง 3 นาฬิกา คือ น้ำเย็น และทิศทาง 12 นาฬิกา คือ น้ำ อุณหภูมิห้อง)



- 3 ค่อยๆ ดันคันโยกน้ำเย็น

- 4 ยกคันโยกน้ำเย็นไปที่ 90 องศา เพื่อจ่ายน้ำเย็น (น้ำอุณหภูมิห้อง) อย่างต่อเนื่อง


น้ำแก้วแรกอาจรู้สึกวุ่นเล็กน้อย เนื่องจากน้ำอุณหภูมิห้องถูกผสมออกมากับน้ำเย็น หลังจากแก้วที่ 2 จะจ่ายน้ำตามอุณหภูมิที่เหมาะสม

\* น้ำเย็นและน้ำร้อน แม้ว่าจะปิดสวิตช์ข้างใดข้างหนึ่งแล้ว อุณหภูมิของน้ำกรองอาจจะร้อนหรือเย็นได้เล็กน้อย ภายาระมัดระวัง

### วิธีเข้าโหมดสแตนด์บายฆ่าเชื้อก๊อก

- 1 หมุนวาล์วเปลี่ยนเส้นทางน้ำไหลไปที่ 'น้ำเย็น' โดยสมบูรณ์


▶ หากวาล์วเปลี่ยนเส้นทางน้ำไหลไม่ไปทาง 'น้ำกรอง' หรือไม่ได้ไปที่ 'น้ำเย็น' โดยสมบูรณ์ น้ำภายในถังจะไหลออกมา



- 2 กดปุ่มฆ่าเชื้อ

▶ เลี้ยงปมจะตั้งเฉพาะเวลาไฟฟ้าช็อกกะพริบพร้อมกับเสียงสัญญาณเตือนจะดังทุก 1 นาที


หากมีน้ำไม่เพียงพอสำหรับการฆ่าเชื้อ จะไม่เข้าโหมดสแตนด์บายพร้อมกับเสียงสัญญาณเตือนดัง



- 3 หลังจากตั้งคันโยกน้ำร้อนและเย็น 90 องศา กรุณาวางถ้วยฆ่าเชื้อบนรางน้ำให้ตรงกับทิศทาง แล้วก็วางถ้วยฆ่าเชื้อบนรางน้ำ เพื่อดันคันโยกน้ำร้อนและเย็นกลับไปที่ด้านหลัง

▶ เลี้ยงปมจะตั้งเฉพาะเวลาไฟฟ้าช็อกกะพริบ พร้อมกับเสียงสัญญาณเตือนจะดังทุก 1 นาที

▶ การวางจากล่างขึ้นบนตามภาพ ในตอนนี้น้ำเย็นจะไม่ไหลออกมา



\* หลังจากกดปุ่มฆ่าเชื้อก๊อก ถ้าตั้งคันโยกขึ้น น้ำเย็น น้ำตกค้างปริมาณน้อยจะออกมา

\* กรุณาตรวจสอบว่าไฟฟ้าช็อกกะพริบอยู่หรือไม่แล้วค่อยตั้งคันโยกขึ้น

\* ระหว่างฆ่าเชื้อก๊อก ห้ามกดปุ่มเปิดน้ำร้อน ถ้ากด น้ำร้อนจะจ่ายน้ำต่อเนื่อง อาจจะทำให้เสี่ยงเกิดแผลน้ำร้อนลวก

\* หากต้องการยกเลิก 'การแจ้งเตือน' วิธีการยกเลิกโหมดสแตนด์บายการฆ่าเชื้อด้านล่าง



## วิธีใช้งานการฆ่าเชื้อก๊อก

### วิธียกเลิกโหมดสแตนด์บายฆ่าเชื้อก๊อก

- 1 หลังจากนำถ้วยฆ่าเชื้อออกจากถาดรองน้ำให้ดันคันโยกน้ำร้อน/น้ำเย็นลง
  - ▶ เสียบปลั๊กเฉพาะเวลาไฟฆ่าเชื้อกะพริบ พร้อมกับเสียงสัญญาณเตือนจะดังทุก 1 นาที ถ้ากดปุ่มฆ่าเชื้อ ก่อนจะดันคันโยกลง น้ำเย็นจะจ่ายออกมา
- 2 กรดปุ่มกดปุ่มฆ่าเชื้อ
  - ▶ เปิดสวิตช์น้ำร้อนและน้ำเย็นพร้อมกับเสียบปลั๊กไฟที่เกี่ยวข้องจะแสดง/ดับตามการปิด

### วิธีใช้งาน

- 1 ถักดปุ่มฆ่าเชื้อก๊อก ในโหมดสแตนด์บายฆ่าเชื้อก๊อก(อ้างอิงหน้า 43)การฆ่าเชื้อก๊อกจะทำงาน
  - ▶ ถักดปุ่มฆ่าเชื้อก๊อกเริ่มทำงานไฟจะแสดง 'น้ำร้อน → ฆ่าเชื้อก๊อก → น้ำเย็น'ตามลำดับ และดำเนินการฆ่าเชื้อเป็นเวลา 3 นาที
    - ※ ระหว่างดำเนินการฆ่าเชื้อ ห้ามนำถ้วยฆ่าเชื้อออก
    - ※ ถ้านำถ้วยฆ่าเชื้อออก การฆ่าเชื้อจะยกเลิกพร้อมกับมีเสียงเตือน และเข้าสู่ 'การฆ่าเชื้อผิดพลาด' (อ้างอิงวิธียกเลิกข้อผิดพลาดของถ้วยฆ่าเชื้อด้านล่าง )
- 2 หากฆ่าเชื้อก๊อกเสร็จสิ้น เสียงเสร็จสิ้นจะพร้อมไฟฆ่าเชื้อกะพริบและเสียงสัญญาณ เตือนจะดังทุก 1 นาที
  - ※ ระหว่างดำเนินการฆ่าเชื้อก๊อก หากต้องการยกเลิกการฆ่าเชื้อ ให้กดปุ่มฆ่าเชื้อซ้ำอีกครั้ง
    - ▶ ฟังก์ชันฆ่าเชื้อสามารถทำได้ทีละครั้ง 1 ไม่สามารถทำต่อเนื่องซ้ำได้
    - ▶ ถักดปุ่มฆ่าเชื้อก๊อกอีกครั้ง ต้องเทน้ำภายในถ้วยฆ่าเชื้อทิ้ง, วางถ้วยบนรางน้ำอีกครั้ง และกดปุ่มฆ่าเชื้อ
    - ※ ถักดปุ่มฆ่าเชื้อก๊อกโดยไม่เทน้ำทิ้ง น้ำยาฆ่าเชื้ออาจจะล้นออกมาได้
    - ※ น้ำยาฆ่าเชื้อ ไม่ใช่สำหรับดื่ม น้ำยาฆ่าเชื้อ ไม่ใช่สำหรับดื่ม กรุณาระมัดระวัง

### วิธียกเลิกข้อผิดพลาดของถ้วยฆ่าเชื้อ

#### แผน 1) วางถ้วยฆ่าเชืบนรางน้ำ(แนะนำ)

- ▶ เสียบปลั๊กเฉพาะเวลาไฟฆ่าเชื้อกะพริบ พร้อมกับเสียงสัญญาณเตือนจะดังทุก 1 นาทีโหมดสแตนด์บายการฆ่าเชื้อ)
- ▶ กรณีที่ถ้วยฆ่าเชื้อออกระหว่างผลิตน้ำฆ่าเชื้อถักดปุ่มฆ่าเชืบนรางน้ำอีกครั้ง จะทำความสะอาดถ้วยฆ่าเชื้อเป็นเวลา 1 นาทีและเข้าสู่โหมดสแตนด์บายการฆ่าเชื้อ ( ไฟฆ่าเชื้อกะพริบและเสียงสัญญาณเตือนจะดังทุก 1 นาที)
- ※ หากต้องการยกเลิกขีผิดพลาดโหมดสแตนด์บายการฆ่าเชื้อกรกดอ้างอิง 'วิธีการยกเลิกโหมดสแตนด์บายการฆ่าเชื้อ' หน้า 42

#### แผน 2) กดปุ่มฆ่าเชื้อ 1 ครั้ง

- ▶ เสียบปลั๊กเฉพาะเวลาไฟฆ่าเชื้อกะพริบ พร้อมกับเสียงสัญญาณเตือนจะดังทุก 1 นาที

ถักดปุ่มฆ่าเชื้ออีก 1 ครั้ง น้ำเย็น/น้ำร้อนจะไหลออกมาในขณะที่น้ำยาฆ่าเชื้อยังคงอยู่ในก๊อกดังนั้นต้องกดคันโยกน้ำเย็น/น้ำร้อนลง หลังจากทำความสะอาดก๊อก(อ้างอิง'วิธีทำความสะอาดก๊อก' หน้า 49) ให้จ่ายน้ำเย็น/น้ำร้อนปริมาณ 2 ถ้วย(300cc) ออกมาแล้วค่อยใช้น้ำอุณหภูมิห้อง


## วิธีการตรวจสอบฟังก์ชันการแจ้งเตือนการเปลี่ยนไส้กรอง



### วิธีการตรวจสอบการเปลี่ยนไส้กรอง

- 1 หลังจากเปิดเครื่องแล้ว การแจ้งเตือนการเปลี่ยนไส้กรองทุก 4 เดือน และการใช้งานของเครื่อง ไฟ LED จะกะพริบที่สัญลักษณ์น้ำเย็น น้ำร้อน และ Faucet Sterilization

※ การแจ้งเตือนไส้กรอง ไฟ LED จะกะพริบ ในขณะที่เปิดใช้งานเครื่องหรือปิดการใช้งานเครื่อง  
 ※ เมื่อทำการปิดเครื่องกรองน้ำ ระยะเวลาของไส้กรองจะถูกรีเซ็ตใหม่




รายการไส้กรอง	ไฟแสดงการเปลี่ยนไส้กรอง
Sediment Filter	เครื่อง ไฟ LED จะกะพริบที่สัญลักษณ์น้ำร้อน
Sediment Filter Pre-Carbon Block 2.0 Filter	เครื่อง ไฟ LED จะกะพริบที่สัญลักษณ์น้ำเย็น
Sediment Filter Natural 2.0 Filter Nano Positive 3.0C Filter	เครื่อง ไฟ LED จะกะพริบที่สัญลักษณ์น้ำเย็นและน้ำร้อน
Sediment Filter Pre-Carbon Block 2.0 Filter Natural 2.0 Filter Nano Positive 3.0C Filter	เครื่อง ไฟ LED จะกะพริบที่สัญลักษณ์น้ำเย็น น้ำร้อน และ Faucet Sterilization

### วิธีการรีเซ็ตการแจ้งเตือนการเปลี่ยนไส้กรอง

วิธีการรีเซ็ตไส้กรอง ในกรณีที่ฟังก์ชันปิดการแจ้งเตือนการเปลี่ยนไส้กรองและเปิดการแจ้งเตือนการเปลี่ยนไส้กรอง

- 1 วิธีการรีเซ็ตไส้กรอง (หากเปิดการแจ้งเตือนการเปลี่ยนไส้กรอง)

- ▶ หลังจากตรวจสอบการแจ้งเตือนการเปลี่ยนไส้กรองแล้ว กดปุ่มฆ่าเชื้อสำหรับก๊อกน้ำ ค้างไว้เป็นเวลา 3 วินาที
- ▶ เลียงที่ปมจะตั้งขึ้นเมื่อฟังก์ชันรีเซ็ตทำงานและสัญญาณการแจ้งเตือนการเปลี่ยนไส้กรองจะปิดลง



- 2 วิธีการรีเซ็ตไส้กรอง (หากไม่ได้เปิดการแจ้งเตือนการเปลี่ยนไส้กรอง)


- ▶ เมื่อทำการเปลี่ยนไส้กรองล่วงหน้าก่อนรอบการเปลี่ยนถัดไป (โดยไม่ต้องเปิดใช้งานการแจ้งเตือนการเปลี่ยนไส้กรอง) ให้ทำการกดปุ่มฆ่าเชื้อสำหรับก๊อกน้ำ ค้างไว้เป็นเวลา 10 วินาที เพื่อรีเซ็ตไส้กรอง
- ※ หากมีการรีเซ็ตการแจ้งเตือนการเปลี่ยนไส้กรองก่อนที่สัญญาณการแจ้งเตือน การแจ้งเตือนสำหรับไส้กรองนั้นจะ ไม่เปิดใช้งานแต่ให้รีเซ็ต ระยะเวลาในการเปลี่ยนไส้กรอง



## วิธีการทำความสะอาดถังน้ำเย็น

### วิธีการใช้งานก๊อกน้ำดื่ม (อุปกรณ์เสริม)




- 1 ถ้าติดตั้งโยกของวาล์วน้ำในครัวที่เชื่อมกับอ่างล้างจานขึ้นไปด้านบน สามารถใช้น้ำในครัวได้
  - ▶ กรณีที่ไม่ได้ใช้น้ำในครัวเป็นเวลานานในขณะที่เชื่อมต่อกับไฟ น้ำของวาล์วน้ำในครัวอาจจะอุ่นเล็กน้อย เนื่องจากความร้อนภายในที่เกิดขึ้นจากการทำงานของฮีตเตอร์หรือคอมเพรสเซอร์
  - ※ กรณีที่ช็อควาล์วน้ำในครัวด้วยแปรงหรือฟองน้ำล้างจาน จะทำให้การเคลื่อนเสียหายได้ และอาจเป็นสาเหตุที่ทำให้เราขาดน้ำเย็น และอื่น ๆ



กรณีที่มิได้ใช้น้ำในครัวนานกว่า 1 วัน น้ำอาจปนเปื้อนได้ หากกลับมาใช้น้ำในครัวอีกครั้ง กรุณาปล่อยน้ำที่ประมาณ 1 - 2 นาที ก่อนใช้

### วิธีการทำความสะอาดถังน้ำเย็น

- 1 ล้างวาล์วจ่ายน้ำ
- 2 ปิดสวิทช์น้ำร้อนและน้ำเย็น
- 3 ดึงปลั๊กไฟออกเพื่อความปลอดภัย
- 4 ระบายน้ำในถังน้ำเย็นออกจนหมด
  - ▶ ปรับวาล์วเปลี่ยนเส้นทางน้ำไหลให้ตรงกับ 'น้ำเย็น'
  - ▶ กรณีที่ไม่ได้ใช้น้ำในครัวเป็นเวลานานในขณะที่เชื่อมต่อกับไฟ น้ำของวาล์วน้ำในครัวอาจจะอุ่นเล็กน้อย เนื่องจากความร้อนภายในที่เกิดขึ้นจากการทำงานของฮีตเตอร์หรือคอมเพรสเซอร์
  - ▶ เตรียมถังน้ำขนาดที่พอดีกับปริมาณน้ำ 3.8 ลิตร




## วิธีการทำความสะอาดถังน้ำเย็น




### 5 เชื่อมต่อสายยางระบายน้ำร้อนที่ระบายน้ำร้อนและก๊อกน้ำร้อนเพื่อระบายน้ำภายในถังน้ำร้อนออกจนหมด

- ▶ เตรียมถังน้ำขนาดที่พอดีกับปริมาณน้ำ 2.5 ลิตร สำหรับเครื่องแบบตั้งพื้น และ 1.4 ลิตร สำหรับเครื่องแบบตั้งโต๊ะ
- ▶ ถั้ระบายน้ำร้อน ก่อนระบายน้ำเย็น ปริมาณน้ำที่ออกมา สำหรับเครื่องแบบตั้งพื้นคือ 3.5 ลิตร และสำหรับเครื่องแบบตั้งโต๊ะคือ 2.4 ลิตร ควรระบายน้ำเย็นก่อนระบายน้ำร้อน(หลังจากระบายน้ำร้อนทั้งหมดแล้ว, ต้องล๊อคด้วยฝาชองวาล์วระบายน้ำ)




### 6 ถอดฝาปิดด้านบนของผลิตภัณฑ์ออก

- ▶ จำเป็นต้องใช้ไขควง '+'



### 7 หลังจากถอดฝาปิดถังน้ำเย็นแล้ว ให้ดึงแผ่นกันออก แล้วถอดออกจากถังน้ำเย็น (ก่อนถอดฝาปิด ให้แกะท่อและไฟที่เชื่อมต่ออยู่ก่อน)


- ▶ เวลาเช็ดภายในถังน้ำ กรุณาสวมถุงมืออนามัยเพื่อความสะอาด



### 8 เช็ดภายในถังน้ำด้วยผ้านุ่มที่ถูกต้องตามสุขอนามัย

- ▶ ระวังไม่ให้สิ่งแปลกปลอมเอาไวภายในถังน้ำ

อาจเกิดอนุภาคสีขาวเนื่องจากแร่ธาตุที่ละลายภายในถังน้ำ การที่ใส่เครื่องกรองน้ำไม่บ่อย ให้ระบายน้ำในถัง 2 - 3 วันครั้ง ผ่านก๊อกน้ำร้อนและน้ำร้อนจะสามารถป้องกันการเกิดอนุภาคสีขาวได้ (ใช้น้ำที่กรองแล้วอย่างรวดเร็วจะดีที่สุด)



### 9 เทน้ำที่ระบายจากข้อ 4 ลงในถังน้ำ แล้วล้างถังให้สะอาด

- ▶ ระบายน้ำที่ใช้ล้างผ่านก๊อกน้ำเย็นให้หมด
- ▶ หลังจากเปิดฝาชองวาล์วระบายน้ำร้อน และระบายน้ำออกจากถังน้ำร้อนจนหมดแล้วปิดล๊อคฝาชองวาล์วให้แน่น






## วิธีการทำความสะอาดถึงน้ำเย็น

### 10 ประกอบแผ่นกันบนถึงน้ำเย็นอีกครั้ง

- ▶ กดอย่างระมัดระวังเพื่อให้แผ่นกันหลุดออกมา


หากแผ่นกัน ไม่แน่นและหลุดออกมา จะเป็นสาเหตุทำให้คอมเพรสเซอร์ทำงานนานขึ้นและเกิดเสียงรบกวน ใส่แผ่นกันให้แน่น



### 11 ประกอบฝาปิดถึงน้ำเย็น


- ▶ ปิดฝาถึงน้ำเย็นให้แน่น

อาจมีแรงสั่นหรือเสียงแปลกปลอมเข้าไปได้




### 12 ปิดฝาด้านบนหลังจากชั้นสกรูและเปิดวาล์วจ่ายน้ำ, ตรวจสอบให้แน่ใจว่าน้ำไหลออกมาจากก๊อกน้ำเย็นและก๊อกน้ำร้อน

- ▶ "+" กดวาล์วชั้นสกรูด้วยไขควง



### 13 เสียบปลั๊กไฟ กดปุ่มเปิดน้ำร้อนและน้ำเย็น



- ▶ ตรวจสอบว่าน้ำไหลออกมาจากก๊อกน้ำร้อนแล้ว ให้กดปุ่มเปิดน้ำร้อน  
※ กรุณาทำความสะอาดถึงน้ำเป็นประจำเพื่อการดื่มน้ำที่สะอาดอยู่เสมอ


## วิธีทำความสะอาดถาดรองน้ำ / วิธีทำความสะอาดหัวจ่าย



### วิธีทำความสะอาดถาดรองน้ำ


#### 1 ถอดถาดรองน้ำ

- ▶ ดึงถาดรองน้ำออกจากผลิตภัณฑ์




#### 2 แยกตะแกรงถาดรองน้ำ

- ▶ หลังจากถอดถาดรองน้ำ ให้จับช่องตะแกรงด้านบนถาดรองน้ำขึ้นเพื่อแยกตะแกรงออกมา




#### 3 ทำความสะอาดถาดรองน้ำ

- ▶ เทน้ำเก่าทิ้ง ใช้ผ้านุ่มเช็ดน้ำที่หลงเหลืออยู่



#### 4 ประกอบถาดรองน้ำ




- ▶ หลังจากทำความสะอาดถาดรองน้ำเสร็จสิ้น ให้ประกอบใหม่ตามลำดับตรงกันข้ามกับขั้นตอนถอด



### วิธีทำความสะอาดหัวจ่าย

- ① หมุนที่ครอบก๊อกตามเข็มนาฬิกา
- ② หมุนเอาต์เล็ตของก๊อกตามเข็มนาฬิกา
- ③ ล้างที่ครอบก๊อกและเอาต์เล็ตของก๊อกผ่านน้ำที่ไหล

- ▶ กรุณาสวมถุงมืออนามัยเพื่อความสะอาด







## วิธีการเปลี่ยนไส้กรอง

### วิธีการเปลี่ยนไส้กรอง (กรุณาใช้ไส้กรองของบริษัทของ CUCKOO เท่านั้น)


- 1 ล็อกวาล์วจ่ายน้ำ




- 2 กำจัดแรงดันค้าง (แรงดันที่หลงเหลือ) ภายในท่อออก




- 3 ปิดสวิตช์น้ำร้อนและน้ำเย็น แล้วดึงปลั๊กไฟ



- 4 หมุนคันโยกล็อกประตูฟิลเตอร์ด้านขวาของผลิตภัณฑ์ไปทางคำว่า OPEN, กดตะขอของประตูฟิลเตอร์ แล้วถอดประตูฟิลเตอร์ออก



- 5 ระบายน้ำภายในเครื่องกรองน้ำออกให้หมด








## วิธีการเปลี่ยนไส้กรอง (กรณีผู้ใช้ไส้กรองของบริษัทของ CUCKOO เท่านั้น)

- 6 หลังจากยกไส้กรองที่ต้องการเปลี่ยน ให้ดึงแล้วถอดออก และเปลี่ยนเป็นไส้กรองใหม่, นำไส้กรองแล้วดันเข้าไปข้างใน

▶ อาจมีน้ำไหลออกมาจากไส้กรองกรณีระดับน้ำ น้ำที่ไหลออกมาจากไส้กรอง ไม่ใช่ น้ำรั่วจากผลิตภัณฑ์



- 7 หลังจากเปลี่ยนไส้กรองเสร็จแล้ว ให้ปิดฝาไส้กรองและปล่อยให้ไหลตรงกับ Case ด้านล่างผ่านสายยางของรูจ่ายน้ำ (ต้องเปิดวาล์วน้ำดิบ น้ำถึงไหลออกมา)




Case 1. ตอนเปลี่ยน SEDIMENT : ปล่อยให้ น้ำไหลออกประมาณ 5 นาที

Case 2. ตอนเปลี่ยน SEDIMENT และ PRE-CARBON BLOCK 2.0 :  
ปล่อยให้ น้ำไหลออกประมาณ 7 นาที

Case 3. ตอนเปลี่ยน SEDIMENT, NATURAL 2.0 และ NANO POSITIVE 3.0C :  
ปล่อยให้ น้ำไหลออกประมาณ 10 นาที

Case 4. ตอนเปลี่ยนทั้งหมด(ตอนติดตั้งผลิตภัณฑ์ช่วงแรก ๆ) :  
ปล่อยให้ น้ำไหลออกประมาณ 10 นาที

<เครื่องแบบตั้งโต๊ะ>







## วิธีการเปลี่ยนไส้กรอง

### วิธีการเปลี่ยนไส้กรอง (กรุณาไส้กรองของบริษัทของ CUCKOO เท่านั้น)


- 8 ปิดฝาทางด้านขวาของผลิตภัณฑ์อีกครั้ง หมุนคันโยกล็อกประตูไปที่คำว่า CLOSE



- 9 เปิดวาล์วจ่ายน้ำดิบ เติมน้ำให้เต็มถัง แล้วระบายออกซ้ำ 2 ครั้ง



- 10 หลังจากเติมน้ำจนเต็มถึงน้ำ เียบปลั๊กไฟแล้วเปิดสวิตช์น้ำร้อนและน้ำเย็น



## ระยะเวลาในการเปลี่ยนไส้กรอง / คำแนะนำ / ลำดับในการใส่ไส้กรอง



### ระยะเวลาในการเปลี่ยนไส้กรอง

- ▶ กำหนดรอบการเปลี่ยนฟิลเตอร์ตามมาตรฐานการใช้งาน 10 ลิตร ต่อ 1 วันในครัวเรือน อาจเปลี่ยนแปลงได้ขึ้นอยู่กับสภาพน้ำดิบ

รุ่นที่ใช้	ชื่อฟิลเตอร์	ระยะเวลาในการเปลี่ยนไส้กรอง
CP-WN601HW	SEDIMENT	4 เดือน
	PRE-CARBON Block 2.0	8 เดือน
	NATURAL 2.0	12 เดือน
	NANO 3.0C	12 เดือน

### คำแนะนำ


#### ▶ ปริมาณน้ำที่มีประสิทธิภาพ

หมายถึงปริมาณน้ำขั้นต่ำที่สามารถกำจัดสิ่งปนเปื้อนได้อย่างมีประสิทธิภาพ โดยไม่ต้องทำความสะอาด, รีไซเคิล และเปลี่ยนฟิลเตอร์ด้านในเครื่องกรองน้ำ

#### ▶ รอบการเปลี่ยนไส้กรอง

รอบการเปลี่ยนไส้กรองหมายถึงรอบการใช้งานที่คาดการณ์ไว้ (ช่วงเวลา) ที่ไส้กรองสามารถทำงานได้อย่างถูกต้อง รอบการเปลี่ยนไส้กรองอาจลดลงเนื่องจากการใช้งานหนัก เพราะมาตรฐานของรอบการใช้งานได้กำหนดไว้ภายใต้เงื่อนไขที่นำประปาที่ใช้เป็นน้ำประปาที่มี ปริมาณประมาณ 10 ลิตร (น้ำดื่มสำหรับ 4 คน) ต่อวัน

### ลำดับในการใส่ไส้กรอง



## ติดต่อฝ่ายบริการ

▼ กรณีที่ใช้งาน ไม่ถูกต้องตามวิธีการใช้งาน แม้ผลิตภัณฑ์จะไม่เสียหาย แต่ผลิตภัณฑ์อาจจะไม่ทำงานตามปกติ หากฟังก์ชันผลิตภัณฑ์ ผิดปกติ ให้ลองตรวจสอบตามรายการตรวจสอบด้านล่าง แต่ถ้ายังมีสิ่งผิดปกติอยู่ กรุณาสอบถามที่ฝ่ายบริการลูกค้า

อาการ	รายการตรวจสอบ	มาตรการดำเนินการ
น้ำรสชาติแปลกหรือมีกลิ่นใหม่ในน้ำ	<ul style="list-style-type: none"> <li>• ไม่ได้ใช้น้ำกรองเป็นเวลานานหรือไม่?</li> <li>• ได้เวลาเปลี่ยนฟิลเตอร์แล้วหรือไม่?</li> <li>• ไม่ได้ใช้น้ำร้อนเป็นเวลานานหรือเปล่า?</li> </ul>	<ul style="list-style-type: none"> <li>• หลังจากระบายน้ำร้อนและเย็นทีละทีในถังทิ้ง กรุณาทำความสะอาดถังน้ำเย็น</li> <li>• กรุณาเปลี่ยนเป็นฟิลเตอร์ของแท้</li> <li>• ระบายน้ำในถังน้ำร้อนทิ้งด้วยสายยางระบายน้ำร้อน, กรุณาใช้น้ำร้อนในชีวิตประจำวันจากก๊อกฝักร้อนเป็นประจำ</li> </ul>
น้ำไม่ไหลออกมา	<ul style="list-style-type: none"> <li>• การจ่ายน้ำดื่มราบรื่นหรือไม่?</li> <li>• แรงดันน้ำในเครื่องต่ำหรือไม่?</li> <li>• น้ำเย็นไหลออกมา แต่น้ำร้อนไม่ไหลออกมาหรือไม่?</li> <li>• เหมือนตันโยกน้ำร้อนและน้ำเย็นน่าจะเสียหรือไม่?</li> </ul>	<ul style="list-style-type: none"> <li>• เปิดวาล์วจ่ายน้ำดิบ</li> <li>• ตรวจสอบว่าสายยางจ่ายน้ำหักหรือไม่</li> <li>• ตรวจสอบว่ามีกาวติดน้ำอยู่หรือไม่</li> <li>• ติดตั้งปั้มน้ำภายนอก (อะไหล่)/กรุณาติดต่อฝ่ายบริการลูกค้า</li> <li>• กดปุ่มแช่ฟัดน้ำร้อน ระหว่างที่ตันโยกน้ำร้อน</li> <li>• ตรวจสอบว่าไฟน้ำร้อนติดอยู่หรือไม่</li> <li>• ตรวจสอบว่าไฟแช่เครื่องหรือไม่</li> <li>※ หากเครื่องไม่ทำงานหลังจากตรวจสอบตามมาตรการดำเนินการด้านบนแล้ว กรุณาติดต่อฝ่ายบริการลูกค้า</li> <li>• กรุณาติดต่อฝ่ายบริการลูกค้า</li> </ul>
อุณหภูมิของน้ำร้อนไม่สูง	<ul style="list-style-type: none"> <li>• ไม่ได้ใช้น้ำกรองเป็นเวลานานหรือไม่?</li> <li>• ได้เวลาเปลี่ยนฟิลเตอร์แล้วหรือไม่?</li> <li>• ไม่ได้ใช้น้ำร้อนเป็นเวลานานหรือเปล่า?</li> </ul>	<ul style="list-style-type: none"> <li>• กดปุ่มน้ำร้อนเพื่อเปิดไฟน้ำร้อน</li> <li>• ขณะสูบน้ำที่มากกว่าปริมาณในถังน้ำร้อน จำเป็นต้องใช้ เวลาทำให้อุ่น(ประมาณ 30 นาที)</li> <li>• กดปุ่มน้ำร้อนที่ด้านหลังผลิตภัณฑ์ และกรุณาติดต่อฝ่ายบริการลูกค้า</li> </ul>

## ติดต่อฝ่ายบริการ

- ▼ กรณีที่ใช้งานไม่ถูกต้องตามวิธีการใช้งาน แม้ผลิตภัณฑ์จะไม่เสียหาย แต่ผลิตภัณฑ์อาจจะไม่ทำงานตามปกติ หากฟังก์ชันผลิตภัณฑ์ ผิดปกติ ให้ลองตรวจสอบตามรายการตรวจสอบด้านล่าง แต่ถ้ายังมีสิ่งผิดปกติอยู่ กรุณาสอบถามที่ฝ่ายบริการลูกค้า

อาการ	รายการตรวจสอบ	มาตรการดำเนินการ
อุณหภูมิของน้ำเย็นไม่เย็น	<ul style="list-style-type: none"> <li>• ไฟน้ำเย็นเปิดอยู่หรือไม่?</li> <li>• ลมบน้ำเย็นปริมาณมากหรือไม่?</li> <li>• ตำแหน่งหลังผลิตภัณฑ์ระบายอากาศได้ดี?</li> </ul>	<ul style="list-style-type: none"> <li>• กดปุ่มน้ำเย็นเพื่อเปิดไฟน้ำเย็น</li> <li>• ชดเชยลมบน้ำที่มากกว่าปริมาณในถังน้ำเย็น จำเป็นต้องใช้เวลาทำให้น้ำเย็น (ประมาณ 1 ชั่วโมง)</li> <li>• ตรวจสอบว่าคอนเดนเซอร์ที่อยู่ด้านหลังของผลิตภัณฑ์ ถูกกั้นอยู่หรือไม่และกำจัดสิ่งกีดขวางอยู่</li> <li>• กรุณาเคลื่อนย้าย ไปยังพื้นที่ระบายอากาศได้ดี</li> </ul>
ปริมาณน้ำลดลงแบบกะทันหัน	<ul style="list-style-type: none"> <li>• ล็อกวาล์วจ่ายน้ำดับอยู่หรือไม่?</li> <li>• รอยเปลี่ยนฟิลเตอร์ผ่านไปแล้วใช่หรือไม่?</li> </ul>	<ul style="list-style-type: none"> <li>• เปิดวาล์วจ่ายน้ำดับ</li> <li>• กรุณาเปลี่ยนเป็นฟิลเตอร์ของแท้</li> </ul>
เสียงรบกวนดังมาก	<ul style="list-style-type: none"> <li>• จุดที่ติดตั้งผลิตภัณฑ์เป็นพื้นราบหรือไม่?</li> <li>• สัมผัสกับสิ่งของอื่น ๆ หรือไม่?</li> <li>• เสียงรบกวนดังหลังจากลบน้ำจากก๊อกหรือไม่?</li> <li>• มีเสียงรบกวนดังระหว่างป้อนน้ำทำงานหรือไม่?</li> </ul>	<ul style="list-style-type: none"> <li>• กรุณาติดตั้งบนพื้นเรียบและแข็งแรง</li> <li>• ห้ามตั้งโดยสัมผัสกับสิ่งของอื่น ๆ</li> <li>• เพราะเครื่องกรองน้ำเป็นวิธีการเชื่อมต่อกับน้ำประปาโดยตรง น้ำกรองจะถูกเติมให้เต็มโดยการไหลผ่านก๊อก เสียงรบกวนที่เกิดขึ้นคือเสียงน้ำเย็นที่ไหลเข้าถังน้ำเป็นการทำงานที่น้ำกรองไหลเข้าตามปกติ</li> <li>• หลังจากลบน้ำ, เพื่อจ่ายน้ำกรองใส่ถังน้ำ จะมีเสียงของป้อนน้ำที่ทำงาน ซึ่งเป็นการทำงานตามปกติ</li> </ul>
มีสารแขวนลอยในน้ำ	<ul style="list-style-type: none"> <li>• รอยเปลี่ยนฟิลเตอร์ผ่านไปแล้วใช่หรือไม่?</li> </ul>	<ul style="list-style-type: none"> <li>• กรุณาเปลี่ยนเป็นฟิลเตอร์ของแท้</li> </ul>
น้ำรั่วออกมาจากเครื่องกรองน้ำ	<ul style="list-style-type: none"> <li>• เหมือนการประกอบ(การเชื่อมต่อ)มีส่วนที่ผิดพลาดหรือไม่?</li> </ul>	<ul style="list-style-type: none"> <li>• กรุณาถอดวาล์วน้ำประปา ดึงปลั๊กออกจากเต้ารับ และส่งคำร้องไปที่ฝ่ายบริการ</li> <li>• หากความเย็นภายในเครื่องกรองน้ำเจอกับความชื้น อาจเกิดปรากฏการณ์น้ำค้างได้ ซึ่งเป็นปรากฏการณ์เดียวกับหยดน้ำในแก้วน้ำ</li> </ul>

THA

## ข้อกำหนดของผลิตภัณฑ์

ชื่อผลิตภัณฑ์		เครื่องกรองน้ำร้อนและเย็นไฟฟ้า CUCKOO			
จำแนก		เครื่องแบบตั้งโต๊ะ			
รุ่น		CP-WN601HW SERIES			
แรงดันไฟฟ้า (โวลต์) / ความถี่ (เฮิร์ต)		แพลตฟอร์ม, 220V~ / 50Hz			
กำลังไฟ (วัตต์)		450วัตต์ (น้ำเย็น : 0.6A น้ำร้อน : 350วัตต์)			
ระบบการกรอง		ใช้ระบบไฟฟ้าและดูดซับในการตลอด			
ไส้กรอง ระยะเวลาในการเปลี่ยน ไส้กรอง		SEDIMENT (4 เดือน)	PRE-CARBON BLOCK 2.0 (8 เดือน)	NATURAL 2.0 (12 เดือน)	NANO POSITIVE 3.0C (12 เดือน)
ความจุ	น้ำกรอง	1.0L			
	น้ำเย็น	2.8L			
	น้ำร้อน	1.4L			
	ความจุทั้งหมด	5.2L			
ชนิดของสารทำความเย็น		R-134a			
อุณหภูมิที่ใช้งานได้		16-32 องศาเซลเซียส			
พื้นที่ในการติดตั้ง		สำหรับบ้าน / สำนักงาน (ออฟฟิศ) และใช้ภายนอกอาคาร			
ผลิตภัณฑ์	น้ำหนัก	14.3 kg			
	ขนาด มม (กว้าง) X มม(ลึก) X มม(สูง)	260 x 508 x 508 mm			
แรงดันที่กำหนดให้ใช้		0.05 - 0.39MPa (0.5 - 3.9bar)			

\* เนื้อหาที่ระบุในคู่มือการใช้งาน (ลักษณะภายนอก, ดีไซน์ และข้อกำหนด) สามารถเปลี่ยนแปลงได้เพื่อพัฒนาคุณภาพของผลิตภัณฑ์ได้โดยไม่ต้องแจ้งให้ทราบล่วงหน้า

## การรับประกัน

**Cuckoo Appliances Private Limited** (จากนี้ไปจะเรียกว่า "CUCKOO") เชื่อว่าเครื่องกรองน้ำของคุณเป็นองค์ประกอบสำคัญในชีวิตของคุณที่จะช่วยให้ชีวิตคุณง่ายขึ้นในการปรุงอาหาร ประหยัดน้ำ และมีน้ำดื่มสะอาด อย่างไรก็ตาม การสึกหรอตามปกติจากการใช้งานประจำและอายุที่มากขึ้นอาจเกิดขึ้นกับเครื่องใช้ไฟฟ้า รวมทั้งการทำงานผิดพลาดก็เป็นเรื่องปกติและสามารถเกิดขึ้นได้หากคุณเป็นเจ้าของเครื่องใช้ไฟฟ้านั้นหมายถึงการซ่อมแซมหรือเปลี่ยนใหม่เป็นสิ่งที่ไม่หลีกเลี่ยงไม่ได้ CUCKOO เสนอการรับประกันสำหรับผลิตภัณฑ์ทั้งหมดที่ผลิตโดยบริษัท และให้ความมั่นใจกับผู้ใช้ว่าผลิตภัณฑ์ทั้งหมดของบริษัทปราศจากข้อบกพร่องด้านวัสดุและมีคุณภาพภายใต้การใช้งานและบริบทตามปกติฉบับจากรันที่ซื้อ เมื่อใดก็ตามที่เครื่องกรองเสีย คุณสามารถวางใจได้ใน CUCKOO as a Service (CAAS) เพื่อเชื่อมโยงคุณกับช่างเทคนิคบริการระดับมืออาชีพที่มีคุณสมบัติเหมาะสมซึ่งจะวินิจฉัยความผิดปกติของเครื่องกรองของคุณและเสนอแนะการซ่อมแซมหรือเปลี่ยนใหม่

- ระยะเวลาการรับประกันเริ่มนับจากรันที่ติดตั้งโดยผู้เช่ารายแรกตามที่ระบุไว้ในลำดับการติดตั้ง และมีอายุหนึ่งปีหลังจากนั้น และการรับประกันนี้ไม่สามารถโอนสิทธิ์ระหว่างบุคคลได้
- ในระหว่างเวลาการรับประกันนี้ CUCKOO จะเปลี่ยนหรือซ่อมแซมชิ้นส่วน/อุปกรณ์เสริมที่ CUCKOO หรือ ASP (ผู้ให้บริการที่ได้รับอนุญาต) เห็นว่าอาจมีข้อบกพร่องในการทำงานเนื่องจากวัสดุหรือฝีมือการผลิตมีข้อบกพร่อง (เช่น ข้อบกพร่องในการผลิต) การรับประกันนี้ครอบคลุมเฉพาะการซ่อมแซมเท่านั้น และไม่ให้สิทธิ์ลูกค้าในการเปลี่ยนผลิตภัณฑ์ การรับประกันนี้ไม่ครอบคลุมถึงวัสดุสิ้นเปลือง (ไส้กรองทั้งหมดที่อยู่ภายในและตัวเครื่องที่เป็นพลาสติก) อย่างไรก็ตาม หากไส้กรองอุดตันภายในหกเดือนแรก ทางเราจะทำความสะอาด / ซ่อมแซม / เปลี่ยนใหม่ให้โดยไม่มีค่าใช้จ่ายเพิ่มเติม แต่ทั้งนี้ขึ้นอยู่กับ การตรวจสอบและสอบสวนโดยช่างเทคนิค และขึ้นอยู่กับดุลยพินิจของ CUCKOO แต่เพียงผู้เดียว
- ความรับผิดชอบบริษัทภายใต้การรับประกันนี้จะยังคงมีผลเฉพาะในกรณีที่ผลิตภัณฑ์ได้รับการติดตั้งอย่างถูกต้องโดย CUCKOO หรือตัวแทนที่ได้รับอนุญาต ณ สถานที่ที่ระบุไว้ในใบแจ้งหนี้ และการติดตั้งดังกล่าวดำเนินการโดยบริษัทหรือตัวแทนที่ได้รับอนุญาต บริษัทจะให้ความพยายามอย่างเต็มที่ในการดูแลหรือซ่อมแซมเกี่ยวกับความล้มเหลวใด ๆ ที่ลูกค้ายื่นร้องเรียนเกี่ยวกับการดูแลลูกค้าของ CUCKOO โดยที่ บริษัทจะดำเนินการซ่อมแซมหรือเปลี่ยนใหม่ ไม่ว่าจะใดก็ตาม หากตัวแทนบริการที่ได้รับอนุญาตของบริษัทพิจารณาแล้วว่าสิ่งเหล่านี้เป็นข้อบกพร่องจากการผลิต
- ลูกค้าต้องแสดงใบเสร็จรับเงินที่จริงและใบรับประกันที่มีตราขายของผู้จำหน่ายประทับไว้ ตลอดจนระบุวันที่ซื้อสินค้า และนำตัวเครื่องมาพร้อมกันชิ้นส่วนที่เสียหายให้ครบชุด หากไม่สามารถแสดงเอกสารดังกล่าว บริษัทจะถือว่าไม่เข้าเกณฑ์การรับประกัน

## การรับประกัน

5. ในกรณีของการซ่อมแซมชิ้นส่วนใด ๆ ในระหว่างระยะเวลาการรับประกันดังกล่าว การรับประกันจะดำเนินต่อไปหลังจากนั้นเฉพาะระยะเวลาที่ยังไม่สิ้นสุดของระยะเวลาการรับประกันเดิมเท่านั้น ชิ้นส่วนที่ชำรุดจะเป็นของ CUCKOO บริษัทของสงวนสิทธิ์ในการตัดสินใจในการเปลี่ยนชิ้นส่วนที่ชำรุดด้วยสิ่งทดแทนโดย ไม่กระทบต่อประสิทธิภาพของผลิตภัณฑ์
6. การรับประกันนี้จะ ไม่ครอบคลุม ไปถึง ผลิตภัณฑ์หรือชิ้นส่วนใด ๆ ที่ได้รับการติดตั้ง/ซ่อมแซมโดยบุคคลที่ไม่ได้รับอนุญาต หรือการซ่อมแซม/ใช้ผลิตภัณฑ์หรืออุปกรณ์เสริมอื่นใดนอกเหนือจากที่บริษัทกำหนด ซึ่งครอบคลุมถึงอุบัติเหตุระหว่างขนส่ง การจัดกาที่ไม่เหมาะสม ฝนเอวอง การปรับแต่ง/ดัดแปลงโดยไม่ได้รับอนุญาต นำไฟหรือมีสิ่งแปลกปลอมทางชีวภาพเกิดขึ้น แรงดันไฟเกินที่ระบุในข้อแนะนำ การจลาจล การใช้งานเชิงพาณิชย์ ฟาผ่า ใช้งานผิดวิธีจากที่ระบุในคู่มือ หมายเลขเครื่องจักรชัดเจน ทำสำเนา หรือเปลี่ยนแปลง ไฟไหม้ น้ำท่วมหรือภัยธรรมชาติ น้ำ การมีอยู่ของวัตถุแปลกปลอมหรือสิ่งมีชีวิต (เช่น หนู จิ้งจก แมลง มด ฯลฯ) ภายในตัวผลิตภัณฑ์ การใช้งานเครื่องเป็นต่าง/กรตที่มีฤทธิ์กัดกร่อนผลิตภัณฑ์ การเปลี่ยนแปลงหรือข้อบกพร่องใด ๆ ที่เกิดจากการบำรุงรักษาที่ไม่เหมาะสม
7. ตัวเครื่องด้านนอกของผลิตภัณฑ์ ไม่อยู่ภายใต้การรับประกัน ดังนั้นจึงต้องจัดการด้วยความระมัดระวังเพื่อป้องกันการแตกหัก ความเสียหายดังกล่าวจะต้องรับผิดชอบตามนโยบายของบริษัท
8. การรับประกันนี้จะถือเป็นโมฆะหากเครื่องใช้งาน/มีการป้อนน้ำอื่นที่ไม่ใช่จากหน่วยงานเทศบาล หรือใช้น้ำบาดาล หรืออยู่ภายใต้อุณหภูมิสูงกว่า 40°C
9. ผลิตภัณฑ์ที่ส่งคืนให้กับ CUCKOO หรือ ASP เพื่การตรวจสอบการรับประกันจะต้องขนส่งคืนด้วยค่าใช้จ่ายล่วงหน้า ไปยังศูนย์บริการที่ได้รับอนุญาต การรับประกันนี้ไม่ครอบคลุมค่าแรง ค่าขนส่งผลิตภัณฑ์จากสถานที่ติดตั้งไปยังศูนย์บริการที่ได้รับอนุญาต และค่าใช้จ่ายอีกประชัน ๆ ลูกค้านี้จะต้องรับผิดชอบเอง
10. ข้อตกลงการรับประกันนี้จะ ไม่มีความเพื่อให้ CUCKOO หรือ ASP ต้องรับผิดชอบการบาดเจ็บหรือความเสียหายใด ๆ ที่ทางตรง/ทางอ้อม ที่เป็นผลสืบเนื่องหรือผลโดยบังเอิญต่อบุคคลหรือทรัพย์สิน
11. CUCKOO หรือ ASP จะ ไม่รับผิดชอบต่อการซ่อมแซมหรือติดตั้งที่หาโดยไม่ได้รับอนุมัติเปลี่ยนแปลงลักษณะลักษณะเฉพาะสำหรับผลิตภัณฑ์ที่ติดตั้งด้วยสารเหลวยลย ตะกอน หรือการเจริญเติบโตทางชีวภาพ หรือความล้มเหลวอันเกิดจากการขาดการบำรุงรักษาที่เหมาะสม
12. บริษัทจะ ไม่รับผิดชอบหรือว่าผิดนัดต่อความล่าช้าหรือความล้มเหลวในการปฏิบัติงานอันเป็นผลโดยตรงหรือโดยอ้อมจากสาเหตุที่อยู่นอกเหนือการควบคุมตามสมควร รวมถึงความล่าช้าในการซ่อมแซมอันเนื่องมาจาก ไม่มีส่วนประกอบหรืออุปกรณ์เสริมใด ๆ ปัญหาด้านแรงงาน ข้อจำกัดและข้อบังคับของรัฐบาล การเคลื่อน ไหวสาธารณะ สงคราม และสถานการณ์ที่หลีกเลี่ยงไม่ได้อื่น ๆ โดยเฉพาะการนำตัววัสดุสิ้นเปลือง ความเจ็บป่วยการเจ็บป่วยอันเนื่องมาจากการใช้น้ำดื่มจากเครื่องกรองน้ำและวัสดุที่ได้รับการบำรุงรักษาอย่างไม่เหมาะสม หรือหากบริษัทถูกขัดขวาง ไม่ให้ปฏิบัติงานที่ภายใต้การรับประกันนี้
13. ข้อตกลงการรับประกันนี้ ไม่รวมผลิตภัณฑ์/ชิ้นส่วนทั้งหมด หรือความเสียหายต่อส่วนใดส่วนหนึ่งของเครื่องกรองน้ำ ซึ่ง CUCKOO หรือ ASP นำไปใช้ในทางที่ผิดตามความเห็นของ CUCKOO การใช้งานที่ผิด ความประมาทเลินเล่อ การดัดแปลง อุบัติเหตุหรือการทำงานที่ขัดต่อคำแนะนำ ความซุกซน ไม่ได้กับอุปกรณ์เสริมที่ไม่ได้ติดตั้งโดย CUCKOO หรือ ASP หรือได้รับการซ่อมแซมด้วยชิ้นส่วนอื่นนอกเหนือจากที่ผลิตหรือ ด้รับจาก CUCKOO หรือ ASP ความเสียหายที่เกิดจากการแก้ไข น้ำท่วม ไฟไหม้ หรือเหตุคล้าย ๆ ไม่ครอบคลุมถึง การรับประกันนี้ ในการติดตั้งกล่าวทั้งหมดจะมีค่าใช้จ่ายปกติ นอกจากนี้ การรับประกันนี้ไม่ไว้ในกรณีใด จะไม่ขยายไปครอบคลุมถึงการจ่ายเงินค่าตอบแทนใด ๆ ที่ตามหรือการเปลี่ยนหรือการส่งคืนผลิตภัณฑ์ทั้งชิ้น
14. แม้ว่าบริษัทจะพยายามทำทุกวิถีทางเพื่อดำเนินการซ่อมแซมโดยเร็วที่สุด แต่ก็มีภาระบางอย่างชัดเจนว่าบริษัท ไม่มีการผูกพันที่จะตั้งดำเนินการดังกล่าวภายในระยะเวลาที่กำหนด
15. CUCKOO ขอสงวนสิทธิ์ในการเปลี่ยนแปลงหรือปรับปรุงการออกแบบและข้อกำหนดใดตลอดเวลา โดยไม่มีการผูกพันใด ๆ ต่อผู้ที่มีแนวโน้มจะเป็นผู้ซื้อหรือเจ้าของผลิตภัณฑ์ที่ขายก่อนหน้านี้
16. ความซัดแย้ง/ข้อพิพาทใด ๆ ที่เกิดขึ้นจากการซื้อผลิตภัณฑ์ CUCKOO จะต้องอยู่ภายใต้และตีความตามกฎหมายของอินเดีย และอยู่ภายใต้เขตอำนาจศาลของศาลมีนัดลิทเทิน
17. CUCKOO หรือ ASP จะ ไม่รับผิดชอบในการรับประกันที่เกี่ยวข้องกับเครื่องกรองน้ำ นอกเหนือจากที่ระบุไว้ในที่นี้ การรับประกันนี้ใช้แทนการรับประกันอื่น ๆ ทั้งหมด ทั้งโดยชัดแจ้งหรือโดยนัย รวมถึงการรับประกันความเหมาะสมสำหรับวัตถุประสงค์เฉพาะ CUCKOO หรือ ASP ไม่อนุญาตให้บุคคลหรือตัวแทนใด ๆ รับผิดชอบภาวะผูกพันอื่นใดในการขายเครื่องกรองน้ำ ภาวะผูกพันของบริษัทภายใต้การรับประกันนี้จะจำกัดอยู่เพียงการซ่อมแซมชิ้นส่วนที่เสียหายเท่านั้น วงเงินรับผิดชอบสูงสุดต่อการเรียกร้องใด ๆ ที่เกี่ยวข้องกับผลิตภัณฑ์ ให้พิจารณาตามราคาขายปลีกสูงสุดของผลิตภัณฑ์ที่ซื้อ หรือราคาซื้อจริง แล้วแต่ว่าจำนวนใดจะต่ำกว่า
18. ในกรณีที่เผชิญกับปัญหาในการใช้งานเครื่องกรองน้ำ ลูกค้ามีหน้าที่ต้องดำเนินการติดต่อฝ่ายดูแลลูกค้าของ CUCKOO ด้วยตนเองเพื่อขอความช่วยเหลือในเรื่องดังกล่าว
19. ในกรณีที่ท่านเปลี่ยนที่อยู่ กรุณาแจ้งบริษัทภายใน 15 วัน เพื่อให้บริษัทได้อย่างต่อเนื่อง บริษัทขอปฏิเสธความรับผิดชอบ ในกรณีที่สินค้าไม่สามารถส่งทาง ไปหลังจากท่านย้ายสถานที่ โดยที่ท่านจะต้องเป็นผู้รับผิดชอบค่าใช้จ่ายทั้งหมด สำหรับการปรับเปลี่ยนหรือเพิ่มเติมอุปกรณ์
20. CUCKOO หรือ ASP ไม่สามารถและจะ ไม่รับผิดชอบต่อความเจ็บป่วยหรือการเจ็บป่วยใด ๆ อันเนื่องมาจากการบริโภคหรือน้ำดื่มจากเครื่องกรองน้ำใด ๆ ที่ CUCKOO จัดหา เนื่องจาก CUCKOO หรือ ASP ไม่ได้การควบคุมการบำรุงรักษาและการใช้น้ำใด ๆ เครื่องกรองน้ำ
21. CUCKOO ขอสงวนสิทธิ์ในการเปลี่ยนแปลงหรือปรับปรุงการออกแบบและข้อกำหนดใดตลอดเวลา โดยไม่มีการผูกพันใด ๆ ต่อผู้ที่มีแนวโน้มจะเป็นผู้ซื้อหรือเจ้าของผลิตภัณฑ์ที่ขายก่อนหน้านี้
22. CUCKOO หรือ ASP ไม่รับผิดชอบในการรับประกันที่เกี่ยวข้องกับเครื่องกรองน้ำ นอกเหนือจากที่ระบุไว้ในที่นี้ การรับประกันนี้ใช้แทนการรับประกันอื่น ๆ ทั้งหมด ทั้งโดยชัดแจ้งหรือโดยนัย รวมถึงการรับประกันความเหมาะสมสำหรับวัตถุประสงค์เฉพาะ CUCKOO หรือ ASP ไม่อนุญาตให้บุคคลหรือตัวแทนใด ๆ รับผิดชอบภาวะผูกพันอื่นใดที่เกี่ยวกับภาวะของเครื่องกรองน้ำ
23. ไม่ว่าในกรณีใด ความรับผิดชอบ CUCKOO หรือ ASP จะต้อง ไม่เกินมูลค่าของผลิตภัณฑ์
24. การตัดสินใจทั้งหมดเกี่ยวกับกาซ่อมแซม/เปลี่ยน ไส้กรองหรือชิ้นส่วนใด ๆ ขึ้นอยู่กับดุลพินิจของ CUCKOO
25. ชิ้นส่วนอะไหล่/อุปกรณ์เสริมใด ๆ ทั้งหมดของผลิตภัณฑ์อาจเป็นของแบรนด์/ซัพพลายเออร์ ตามที่ Cuckoo Appliances Private Limited ตัดสินใจภายในแปดครั้งควา การเปลี่ยนแปลงใด ๆ จะ ไม่ถือเป็นสิทธิ์ให้มีการเรียกร้องทางกฎหมายหรือการเรียกร้องต่อบริษัท และจะต้องขึ้นอยู่กับดุลพินิจของ CUCKOO
26. หลังจากประกันหมดอายุ ลูกค้าสามารถเลือกซื้อประกันแบบต่ออายุได้ ในกรณีที่ สินค้ารุ่นนั้นมีบริการประกันแบบต่ออายุพร้อมจำหน่าย โดยทางบริษัท จะคิดราคาตามอัตราและเงื่อนไขที่ประกาศในขณะนั้น



MEMO



MEMO



THA

**CUCKOO**  
By **MEX**

**PEN K INTER TRADING CO., LTD**

**HEAD OFFICE** : 1000/63-64 PB TOWER, 16th Floor. Sukhumvit 71 Road, North Klongtan,  
Wattana, Bangkok 10110 TEL : 02-493-6565 FAX : 02-391-1141

**SERVICE CENTER** : 63/3 Moo 6 Soi Suksawat 76, Bangchak, Phra Pradaeng, Samut Prakan 10130  
TEL : 02-493-6565 FAX : 02-464-1600 E-Mail : service2@penk.co.th

**SALE OFFICE** : 02-493-6565

10383-0023H0 Rev.0